

# Lindab **UltraLink<sup>®</sup> Monitor** **FTMU**

Technical information

# Content

Introduction .....	2
Overview .....	3
Description .....	3
Planning.....	4
Mounting .....	6
Connections .....	6
Power supply.....	8
Display.....	9
Settings .....	9
ID-numbers .....	12
Troubleshooting .....	12
Maintenance.....	12
PIN code.....	12
Technical data .....	13
Airflows.....	13
Appendix A – Modbus register .....	14



## Introduction

UltraLink® FTMU is a highly accurate flow monitor without any obstacles in the airstream that creates pressure drop. It measures the flow with an angled ultrasonic beam which can be calculated and compensated to a very high accuracy over the whole flow range. The method is very stable over time due to that it is not sensitive to dirt and the design minimizes the dust accumulation on the flow sensors.

An increased focus on energy saving has led to ventilation systems requiring low minimum flows. The low flows are a problem since they are very difficult to measure, which makes it difficult to control the ventilation system.

The new technology of UltraLink® makes it possible to measure lower air flows compared to today's products while maintaining measurement accuracy. This offers great advantages for the user in terms of comfort and savings in energy consumption, which is of great interest.

## Overview



## Description

### Application

The Monitor is suitable for measuring air flow and temperature. Communication is established via analog or digital signal using Modbus.


### Design

The Monitor consists of a sensor body with Lindab Safe gaskets.

Two flow sensors are mounted on the sensor body and connected to a display unit. The display unit is mounted on top of a shelf on the sensor body. Since the display and shelf is mounted on the sensor body using a sheet metal strap, the display unit can be rotated relative to the sensorbody.

Positioning the sensor body correctly after a disturbance is crucial for the measurement accuracy, see page 4 for directions on how to mount the Monitor for optimal performance.

**Note! The flow sensors are placed at a fixed distance to each other and they shall never be removed and not used as handles when turning the sensor body.**







## Planning

The longer distance to disturbance, i.e. the longer straight duct before the Monitor, the higher the measurement accuracy will be. However this is not the only factor which affects the accuracy of the measurement. The rotation of the Monitor and hence the positioning of the first flow sensor has an impact on the uncertainty of the measurement. It is not recommended to mount the Monitor so that the first flow sensor (\*) is placed on an outer radius of a fitting.

For example: in the case of the bend in the table below, by rotating the Monitor to position the first flow sensor according to the first picture (with the first flow sensor on the inner radius of the bend), the Monitor can be placed at the distance of two duct diameters from the disturbance to achieve 5 % uncertainty. Positioning the Monitor according to the second picture (with the first sensor on the outer radius of the bend), the Monitor must be mounted five duct diameters from the disturbance to achieve the same level of uncertainty.

Never use an UltraLink® on the outlet side of a duct fan. Place it on the inlet side or in worst case use a flow conditioner if it must be placed on the outlet side. **Minimum straight distance after Monitor is  $1 \times \text{Ød}$ .**

Disturbance	* Placement of first flow sensor	Measurement uncertainty $\pm$ % or X l/s depending which is the greatest, where X equals the diameter in dm, see table on page 13.			
		a			
		2-4·Ød	>4-5·Ød	>5·Ød	
Bend		Inner radius	5	5	5
Bend		Outer radius (Not recommended)	20	10	5
Bend		Side	10	5	5
					

Disturbance	* Placement of first flow sensor	Measurement uncertainty ± % or X l/s depending which is the greatest, where X equals the diameter in dm, see table on page 13.			
		a			
		2-4·Ød	>4-5·Ød	>5·Ød	
Reducer		Duct diameter decrease	5	5	5
Reducer		Duct diameter increase	10	5	5
T-piece		Inner radius	10	5	5
T-piece		Outer radius (Not recommended)	20	10	5
T-piece		Side	10	5	5



## Mounting

Mount the Monitor into the air duct system according to the mounting instructions for Lindab Safe. **Do not use the flow sensors as handles when you mount the Monitor since this may cause damage and changes in their positions might effect the measurement accuracy.**

**Make sure the airflow arrow is pointing in the direction of the airflow.**

Note the ID-number of the Monitor. The ID can be found on the label of the box it was delivered in or on the label on the Monitor itself and are the three last numbers of the serial no.

Position the Monitors sensor body according to the chapter "Planning", loosen the screw on the steel strip holding the display unit in place. Rotate the display unit so that the display is visible from some direction. For future connections it is important that the screws on the lid of the display can be removed. Tighten the screw on the steel strip so that the display unit is fixed to the sensor body.




To be able to connect cords to the terminal board the rubber cable grommet on the backside of the display unit must be punctured, preferably using an awl or something else pointy to ensure tightness to the environment. When the cords have been connected they must be strain relieved. The cords can be attached to the shelf by using cable ties that are attached around cut outs in the shelf.

You must under no circumstances make any holes or connect anything with screws to the sensor body since this will have an impact on measurement accuracy!

## Connections

Connect the Monitor to a remote terminal unit using RS485 or analog terminals. Connections are made in the terminal board which can be accessed when the lid of the display unit is removed.

1. **24V**, power supply (AC G, DC +) \*
2. **GND**, power supply (AC G0, DC -) \*
3. **+B**, connection for Modbus via RS485
4. **-A**, connection for Modbus via RS485
5. **SH**, shield
6. **GND**, ground (system neutral)
7. **AO1**, analog output
8. **AO2**, analog output
9. **AIN**, (not used in this version)
10. **MO1**, (not used in this version)
11. **MO2**, (not used in this version)
12. **GND**, ground (system neutral)
13. **SCL**, not used
14. **SDA**, not used
15. **GND**, ground (system neutral)
16. **3V3**, not used



\*) When using AC terminal 1 (G) should be system potential and terminal 2 (G0) should be system neutral.


Recommendations for wiring:

Function	Cable type
24 V Supply	2-wire, thickness depending on length and load, max. 1,5 mm <sup>2</sup>
RS485	2-wire shielded twisted pair, min. 0,1 mm <sup>2</sup> (LIYCY cable)

Supply the Monitor with power from a transformer.

## Digital connection


Connect A on the RTU to -A on the display unit and B to +B. When connecting more than one Controller in series it is important to keep connecting -A to -A and +B to +B since crossing them will stop Modbus from working. The shield in the RS485 cable should be connected to ground at the transformer and then continuously connect to "SH" on all the UltraLinks that are powered from that transformer. If more than one transformer is used on the bus, the shield is broken at each transformer so "SH" on every product only has connection to ground at the transformer from which it's power is supplied. It is recommended to use RS485 cables with twisted pairs and shield, do not supply power in the same cable unless the cable is produced for that purpose.



## Biasing

The master on the bus must have biasing on -A and +B. This is more or less standard on BMS-controllers, but if communication should be established with a conventional computer using a RS485-USB converter, then it is important to make sure that the converter has a bias circuit. If communication fails and you are uncertain about existence of biasing, you can add biasing resistors in the screw terminal on one of the UltraLinks to see if this is the cause of the communication failure.

Use 500 - 1000  $\Omega$  resistors and connect one resistor from -A to GND and one from +B to the 3V3 terminal. It is also recommended to add a 120  $\Omega$  termination resistor between -A and +B on the last UltraLink on the bus to avoid signal reflections.



## Analog connection

When connecting the Monitor using analog signals, it is important to connect the analog out signals on the Controller (AO1, AO2) to the analog in terminals on the RTU and the analog in signal (AIN) is connected to the analog out terminal on the RTU. Also make sure to connect the cables to the same analog ground.

## Bluetooth® connection

If the product is equipped with **Bluetooth** (the Bluetooth logotype is printed on the display unit), wireless communication with the UltraLink can be established. Using a smartphone or tablet with the Lindab UltraLink App, nearby UltraLinks can be identified. It is then possible to connect to one unit and view information regarding that UltraLink, such as active measurements and settings.

## Mobile app

The app "UltraLink" is available on both Android and iOS, it's free to download from Google Play or App store. Like the PC configuration tool, all settings can be changed via the app. This means all settings can be individually chosen for the specific building, it is therefore necessary to protect the unit with the PIN code in the UltraLink menu. For a discription on how this is done, see page 9.

## Repeater

If the bus is longer than 300 meters or if there are more than 30 devices, the system might need an RS485 repeater (FDS-R, see picture to the right) to be able to communicate in an efficient way.



## Power supply

### Transformer sizing

The needed size of 24 V AC transformer(s) can be defined by adding up the dimensioning power consumption [VA] of all the components. The transformer power must exceed this. Use only safety isolating transformers. Calculation of the current demand I:

$$I = (P_1 + P_2 + \dots + P_n) / U \text{ [A]}$$

where:

$P_n$  is the dimensioned power consumption for each component [VA] U is the voltage (24) [V].

If the current demand I exceeds 6 A ( which corresponds to approximately 150 VA for a 24 V AC transformer ), it is necessary to use more transformers to prevent overheating.

### Supply cable sizing

The wire size of the supply cable can be determined by calculating the resistance per meter R. The calculation presupposes that a voltage drop of e.g. 2 V is accepted in the supply cable:

$$R(\text{per m}) = U_{\text{drop}} / (I * L) \text{ [\Omega/m]}$$

where:

$U_{\text{drop}}$  is the accepted voltage drop (2 V) in the cable [V] I is the current [A]

L is the longest distance of supply cables from transformer to a component [m]

### Power consumption

The power consumption for dimensioning supply cables for an UltraLink® Monitor is 0,5 VA.

**It is not recommended to use a transformer with a higher capacity than 150 VA!**


#### Example:

$$U_{\text{drop}} = 2 \text{ V}, I = 4 \text{ A}, L = 20 \text{ m}$$

$$R(\text{per m}) = 2\text{V} / (4\text{A} \times 20 \text{ m}) = 0,025 \text{ }\Omega/\text{m}$$

In the diagram a Wire cross section Area of 0,7 mm<sup>2</sup> can be read.

### Wire cross section area as a function of resistance per m for copper wire





## Display


The display can show useful information both with the diode flashing in green (status light) and with parameters in the LCD. If the product is equipped with Bluetooth, then the diode will also flash in blue every three seconds. If a device has been connected to the UltraLink via Bluetooth, then the diode will flash in blue every other second. By short pressing the mode button you can change the displayed parameter. If the button is pressed for more than 5 seconds (long press) then the configuration menu will be visible. The arrow at the bottom of the display indicates the current parameter type and unit.

The following parameters can be shown:

- Air flow (m<sup>3</sup>/h)
- Air flow (l/s)
- Air velocity (m/s)
- Temperature (°C)
- Monitor's ID number

The standard setting for the display shows the air flow in m<sup>3</sup>/h.

For a detailed description on configuring the UltraLink using the mode button on the display, see page 11.



## Status light

The status light indicates:

Mode	Function
No light	Monitor is turned off
Flashing light	A problem has occurred
Constant light	Monitor is turned on and functioning as normal

## Settings

All available settings are presented in the appendix. These can be changed via a Bluetooth device and an app, which can be downloaded from Google Play or App Store. The settings can also be changed via the RS485 bus and can be done from any device and configuration that can communicate using Modbus, but preferably the UltraLink® Configuration tool (See separate documentation). Instructions for the most common settings are described below. For more register details see appendix.

### Digital communication settings

Registers 4x001-4x009 are used to configure communication settings. When initializing contact for the first time the default settings will be active;

Modbus id:	Last three digits in the serial number (also visible in the display if the product has power)
Baud rate:	19200
Parity:	Odd
Stop bits:	1

After updating any of the communication parameters the product needs to be power cycled for the changes to take effect. If communication fails with the default parameters selected in the UltraLink® configuration tool, then the communication settings on the Monitor might have been changed previously. Verify the settings in the display (See page 11 for instructions)

### Analog out settings

Analog out is always active but you need to specify what kind of data you want to read on the two ports;

1. Configure registers 4x401 and 4x431 for the variables you want to read on the analog out terminals (0 = Flow, 1 = Temperature).
2. Configure registers 4x400 and 4x430 for analog out level configuration ( (0) 0-10V, (1) 10-0V, (2) 2-10V, (3) 10-2V)
3. Configure registers 4x401–406 and 4x431–436 with relevant data for max and min levels for the voltage range selected in step 2. You only need to configure the max and min values corresponding to the variable selected in step 1.

Size Ø [mm]	4x400 Level Conf.	4x401 Unit Conf.	4x402 Temp Min [°C]	4x403 Temp Max[°C]	4x404 Flow Min [l/s]	4x406 Flow Max [l/s]
100	2 (2-10V)	0 (Flow)	0	50	0	55
125			0	50	0	86
160			0	50	0	141
200			0	50	0	220
250			0	50	0	344
315			0	50	0	546
400			0	50	0	880
500			0	50	0	1374
630			0	50	0	2182

Default values for the relevant registers related to “Analog Out 2” are according to the table below (Default values for flow max corresponds to 7 m/s).

Size Ø [mm]	4x430 Level Conf.	4x431 Unit Conf.	4x432 Temp Min [°C]	4x433 Temp max[°C]	4x434 Flow Min [l/s]	4x436 Flow Max [l/s]
100	2 (2-10V)	1 (Temperature)	0	50	0	55
125			0	50	0	86
160			0	50	0	141
200			0	50	0	220
250			0	50	0	344
315			0	50	0	546
400			0	50	0	880
500			0	50	0	1374
630			0	50	0	2182

## Configuration menu structure

The settings that are related to RS485 communication can also be set via the display. The configuration menu is activated by long pressing the button (5 sec). After long pressing the button the first menu option appears in the display. Toggle to the next menu tag by short pressing the button. Long press to change the setting for the shown menu tag. All menu tags and options are shown in the table below;

Menu tag	Description	Options	Description
• Pr.	Protocol	Pr.PAS Pr.Mod	Pascal protocol Modbus
• b.	Baud rate	b.9600 b.19200 b.38400 b.76800	Baud rate 9600 Baud rate 19200 Baud rate 38400 Baud rate 76800
• bit.	Stop bits	bit.1 bit.2	1 stop bits 2 stop bits
• P.	Parity	P.odd P.even P.none	Odd parity Even parity Parity none
• Id.	Modbus Id	Id.x	Modbus id (x = value) *)
• PLA.	PLA address for Pascal	PLA.x	PLA address (x = value) *)
• ELA.	ELA address for Pascal	ELA.x	ELA address (x = value) *)
• Pi.	Pin-code	Pi.xxxx	Default: xxxx = 1111
• Store	Store changes		Stores changes on long press
• Cancel	Cancel		Cancel and ignore changes on long press

\*) To change the value you need to long press until a blinking cursor appears under the first single number in the current value. After that you short press to toggle to the desired number, then you long press to move the blinking cursor to the next single number in the current value. Proceed until the new value has been set and long press to continue.

**PLEASE LOOK IN THE APPENDED MODBUS REGISTER FOR INSTRUCTIONS ON HOW TO CHANGE REGISTER VALUES. SOME VALUES HAS SCALE FACTORS AND SOME VALUES OCCUPY TWO REGISTERS!**

### PIN code

UltraLink® with Bluetooth must be protected against unauthorized access by PIN-code, which has to be stated before changes to the settings can be made. It is important to choose and change the code that the product is delivered with (1111), to ensure that no unauthorized changes are made.

The code can be changed in three ways:



- using the configuration menu in the display, see page 11 for instructions.
- connecting a PC via Modbus and using the "Configuration Tool" software.
- connect a Bluetooth device and use the "UltraLink" application.

## ID-numbers

The monitors have from production been given an ID-number between 1 to 239. The given ID-number can be seen on the label on the outside of the box the monitor is delivered in, the ID-number is the same as the three last digits in the serial number.

If two or more monitors have the same ID-number it is necessary that each of them get an unique ID-number to allow communication.

To change the Modbus ID register of an UltraLink® all other devices with the same ID must be disconnected. It is more efficient to change the ID in the display under "Con.Set" (See page 9 for more info). The register for Modbus ID is a holding register with address 4x001.



## Troubleshooting

If a problem occurs the status light will start to flash and an error code will be displayed.

If communication fails, please verify the following before contacting support:

- Check settings for Baud rate, parity and stop bit and make sure the master uses the same settings as the UltraLinks.
- -A and +B are continuously connected between all the products without any mixups of -A and +B. Star connection is not allowed.
- The cables for power supply are connected identical on all products and transformers connecting G to G (24V) and G0 to G0 (GND).
- The shield is continuous along the bus and grounded only at the transformer and the last UltraLink on the bus.
- There are not more than 30 devices on the bus. (Try a repeater if you have more than 30 devices.)
- The total length of the bus is maximum 300 m. (Try with a repeater if you have more than 300 m bus cable.)
- Try to establish communication with a PC using Control Center and a biased RS485-USB converter.

Error code	Problem	Comment
Err004	Problems with flow measurement	Might be caused by: <ul style="list-style-type: none"> <li>• something blocking the flow sensors</li> <li>• an electronic fault</li> <li>• the flow sensors are not connected properly into the display unit</li> <li>• the sensor body is flawed</li> </ul>
Err032	Factory data is corrupted	Reset to factory defaults using UltraLink® configuration tool

## Maintenance

Normally does not require any maintenance.

The visible parts of the device can be wiped with a damp cloth.

## Technical data

Power supply	DC	24 (18-32) V
	AC	24 (24-28) V
Cable	Max outer diameter	7 mm
Power consumption		0,4 W
Power consumption	For wiring	0,5 VA
IP class		42
Tightness class to the environment	EN 12237	D
Storage temperature range		-30 to +50 °C
Maximum ambient moisture		95 % RH
Connection	RS485 standard or analog	
Cable	RS485 standard cable, 2-wire shielded twisted pair, min. 0,1 mm <sup>2</sup> (LIYCY cable)	
Protocol	Modbus	
Output	Flow	m <sup>3</sup> /h
	Flow	l/s
	Velocity	m/s
	Temperature	°C
Velocity range	For guaranteed measurement uncertainty	0,2 - 15,0 m/s
Measurement uncertainty, flow (min. 5 diameters of straight duct before the Ultra-Link.)	Depending on which is the greatest of the percentage or the absolute value for the specific product size.	±5 % or Dim. 100 = ±1,00 l/s Dim. 125 = ±1,25 l/s Dim. 160 = ±1,60 l/s Dim. 200 = ±2,00 l/s Dim. 250 = ±2,50 l/s Dim. 315 = ±3,15 l/s Dim. 400 = ±4,00 l/s Dim. 500 = ±5,00 l/s Dim. 630 = ±6,30 l/s
Temperature range		-10 to +50 °C
Measurement uncertainty temperature		±1 °C
Screws on lid of display unit	TX10	4 pcs
Bluetooth signal	Frequency	2402 – 2480 MHz
	Output power	-40 to +9 dB

## Airflows

Ø [mm]	0,2 m/s		7,0 m/s		15,0 m/s	
	m <sup>3</sup> /h	l/s	m <sup>3</sup> /h	l/s	m <sup>3</sup> /h	l/s
100	6	2	198	55	425	118
125	9	3	309	86	662	184
160	14	4	507	141	1087	302
200	23	6	792	220	1696	471
250	35	10	1237	344	2650	736
315	56	16	1964	546	4208	1169
400	90	25	3167	880	6786	1885
500	141	39	4948	1374	10603	2945
630	224	62	7855	2182	16833	4676

## Appendix A – Modbus register

- Address : Modbus register address (3x indicates Input & 4x indicates Holding)
- UltraLink® : Type of UltraLink® where the register is available (Indicated by “x”)
- Name: Name of register
- Description: Short description of register.
- Data type: Data type for register (16bit contained in one register, 32bit and float in two consecutive registers).
- Unit: Unit for register value (if any).
- Div: Scale factor for stored value (divide register value with “div” to get correct value).
- Default: Default setting.
- Min: Minimum value allowed for the register.
- Max: Maximum value allowed for the register.
- Access: RO for read only (Input registers) and RW for read and write (Holding registers).

Address	UltraLink®		Name	Description	Data type	Unit	Div	Default	Min	Max	Access
	Controller	Monitor									
<b>INPUT REGISTERS</b>											
3x008	X	X	Product Nominal Size	Nominal diameter of duct	16bit	mm					RO
3x013	X	X	Unit Status	Current unit status: 0 = Normal mode; 1 = Locating flow; 2 = Override control; 3 = Error; 4 = Control loop regulating; 5 = Angle sensor calibrating	16bit						RO
<b>Flow info</b>											
3x150	X	X	Velocity in m/s	Average velocity in m/s	Float	m/s					RO
3x152	X	X	Air flow in m³/h	Average air flow in m³/h	Float	m³/h					RO
3x154	X	X	Air flow in l/s	Average air flow in l/s	Float	l/s					RO
<b>Temperature info</b>											
3x200	X	X	Current temperature in °C	Temperature in degree celcius.	16bit	°C	10				RO
<b>Damper info</b>											
3x251	X		Damper open in %	Damper actual position in percentage open.	16bit	%	10				RO
3x252	X		Damper motor action	Damper motor action: 0 = Motor stopped. 1 = Motor opening damper 2 = Motor closing damper	16bit						RO
<b>Alarms</b>											
3x400	X	X	Alarm Register 1	Alarms 1-32 - bitwise: 1 = Motor not working. 2 = Angle sensor not working correctly. 3 = Flow setpoint not reached. 4 = Flow measure problems. 5 = Damper is regulating. 6 = Not used. 7 - 31 = Reserved for future use. 32 = Factory data is corrupted.	32bit						RO
<b>Other</b>											
3x500	X	X	Signal amplification	Current signal amplification	16bit			0	3	20	RO

Address	UltraLink®		Name	Description	Data type	Unit	Div	Default	Min	Max	Access
	Controller	Monitor									
<b>HOLDING REGISTERS</b>											
<b>Communication settings</b>											
4x001	X	X	Communication id	Modbus address	16bit				1	239	RW
4x002	X	X	RS485 Baud Rate Conf.	Baudrate: 0 = 9600 1 = 19200 2 = 38400 3 = 76800	16bit			1	0	3	RW
4x003	X	X	RS485 Parity Conf.	Parity: 0 = Odd; 1 = Even; 2 = None	16bit			0	0	2	RW
4x004	X	X	RS485 Stop Bit Conf.	Number of stopbits: 1 or 2.	16bit			1	1	2	RW
4x005	X	X	RS485 Protocol Conf.	Protocol: 0 = Modbus; 1 = Not used; 2 = Pascal;	16bit			0	0	2	RW
4x006	X	X	Bluetooth Password	Password which must be provided to pair Bluetooth devices. This password can always be changed from wired connection. From wireless it can only be changed when connection is established using current password.	16bit			1111	0000	9999	RW
4x007	X	X	Bluetooth Enable	Enable Bluetooth Communication 0 = Bluetooth turned off; 1 = Bluetooth turned on;	16bit			1	0	2	RW
4x008	X	X	PLA	ID used for Pascal	16bit				1	239	RW
4x009	X	X	ELA	ID used for Pascal	16bit				1	239	RW
4x010	X	X	Bluetooth TX Power Level	Configure TX Power Level dBm. Accepted values: -40, -20, -16, -12, -8, -4, 0, 2, 3, 4, 5, 6, 7, 8, 9	16bit			0	-40	9	RW
<b>System configuration</b>											
4x070	X		Damper Regulation Conf.	Specifies how damper is regulated: 0 = Regulator turned off 1 = Regulate damper angle 2 = Regulate flow	16bit			2	0	2	RW
4x071	X		Damper Input Conf.	Specifies input to control damper: 0 = Modbus or Pascal 1 = Analog input	16bit			1	0	1	RW
4x082	X	X	Execute Factory Reset	Factory reset of all parameters. Unit will restart 0 = Do nothing; 1 = Factory Reset	16bit			0	0	1	RW
4x083	X	X	Execute Reboot	Reboot the unit 0 = Do nothing; 1 = Reboot the unit;	16bit			0	0	1	RW
<b>Override configuration</b>											
4x150	X		Damper Override Timeout	Time before returning to normal mode	16bit	min		120	0	600	RW
4x151	X		Damper Override Conf.	0 = Normal mode; 1 = Override control - Max open; 2 = Override control - Min open; 3 = Override control - 100% open; 4 = Override control - 100% closed	16bit			0	0	4	RW
<b>Damper</b>											
4x300	X		Execute Angle Calibration	0 = Do nothing; 1 = Start recalibration of the angle sensor; 2 = Start recalibration when starting up;	16bit			0	0	2	RW
4x302	X		Angle Set Point	Angle setpoint used in normal mode. (Only relevant when 4x070 is set to 1 )	16bit	%		0	0	100	RW

\* = the value depends on the dimension of the product.

Address	UltraLink®		Name	Description	Data type	Unit	Div	Default	Min	Max	Access
	Controller	Monitor									
4x314	X		Flow Set Point	Flow setpoint used in normal mode. (Only relevant when 4x070 is set to 2 )	16bit	l/s		*	0	4700	RW
4x315	X		Flow Set Point Minimum	Flow setpoint min.	16bit	l/s		*	0	4700	RW
4x316	X		Flow Set Point Maximum	Flow setpoint max.	16bit	l/s		*	0	4700	RW
<b>Analog output</b>											
4x400	X	X	Analog Output 1 Level Conf.	Analog output config: 0 = 0-10V, 1 = 10-0V, 2 = 2-10V, 3 = 10-2V.	16bit			2	0	3	RW
4x401	X	X	Analog Output 1 Unit Conf.	Show: 0 = Flow; 1 = Temperature; 2 = Angle;	16bit			0	0	2	RW
4x402	X	X	Analog Output 1 Temp. Min.	Min temperature shown = Min output voltage (Only relevant when 4x401 is set to 1 )	16bit	°C		0	-40	50	RW
4x403	X	X	Analog Output 1 Temp. Max.	Max temperature shown = Max output voltage (Only relevant when 4x401 is set to 1 )	16bit	°C		50	-40	50	RW
4x404	X	X	Analog Output 1 Flow Min.	Min flow shown = Min output voltage (Only relevant when 4x401 is set to 0 )	16bit	l/s		0	-4700	4700	RW
4x406	X	X	Analog Output 1 Flow Max.	Max flow shown = Max output voltage (Only relevant when 4x401 is set to 0 )	16bit	l/s		*	-4700	4700	RW
4x408	X		Analog Output 1 % Open Min.	Min open % shown = Min output voltage (Only relevant when 4x401 is set to 2 )	16bit	%	10	0	0	1000	RW
4x409	X		Analog Output 1 % Open Max.	Max open % shown = Max output voltage (Only relevant when 4x401 is set to 2 )	16bit	%	10	1000	0	1000	RW
4x430	X	X	Analog Output 2 Level Conf.	Analog output config: 0 = 0-10V, 1 = 10-0V, 2 = 2-10V, 3 = 10-2V.	16bit			2	0	3	RW
4x431	X	X	Analog Output 2 Unit Conf.	Show: 0 = Flow 1 = Temperature 2 = Angle	16bit			2	0	2	RW
4x432	X	X	Analog Output 2 Temp. Min.	Min temperature shown = Min output voltage (Only relevant when 4x431 is set to 1 )	16bit	°C		0	-40	50	RW
4x433	X	X	Analog Output 2 Temp. Max.	Max temperature shown = Max output voltage (Only relevant when 4x431 is set to 1 )	16bit	°C		50	-40	50	RW
4x434	X	X	Analog Output 2 Flow Min.	Min flow shown = Min output voltage (Only relevant when 4x431 is set to 0 )	16bit	l/s		0	-4700	4700	RW
4x436	X	X	Analog Output 2 Flow Max.	Max flow shown = Max output voltage (Only relevant when 4x431 is set to 0 )	16bit	l/s		*	-4700	4700	RW
4x438	X		Analog Output 2 % Open Min.	Min open % shown = Min output voltage (Only relevant when 4x431 is set to 2 )	16bit	%	10	0	0	1000	RW
4x439	X		Analog Output 2 % Open Max.	Max open % shown = Max output voltage (Only relevant when 4x431 is set to 2 )	16bit	%	10	1000	0	1000	RW

\* = the value depends on the dimension of the product.



Address	UltraLink®		Name	Description	Data type	Unit	Div	Default	Min	Max	Access
	Controller	Monitor									
<b>Analog input (Settings below are only relevant when register 4x071 is set to 1)</b>											
4x500	X		Analog In Level Conf.	Analog input: 0 = 0-10V, 1 = 10-0V, 2 = 2-10V, 3 = 10-2V.	16bit			2	0	3	RW
4x501	X		Analog In Angle Minimum	Min angle = min voltage	16bit	%		0	0	100	RW
4x502	X		Analog In Angle Maximum	Max = max voltage	16bit	%		100	0	100	RW
4x503	X		Analog In Flow Minimum	Min flow = min voltage (Must be equal or higher than register 4x315)	16bit	l/s		0	0	4700	RW
4x504	X		Analog In Flow Maximum	Max flow = max voltage (Must be equal or lower than register 4x316)	16bit	l/s		*	0	4700	RW
4x510	X		Analog In Override Low Trigger Min.	Lowest voltage level to activate 1st Override level (Only relevant when 4x500 is set to 2 or 3)	16bit	V	10	0	0	20	RW
4x511	X		Analog In Override Low Trigger Max.	Highest voltage level to activate 1st Override level (Only relevant when 4x500 is set to 2 or 3)	16bit	V	10	8	0	20	RW

\* = the value depends on the dimension of the product.



## Good Thinking

**At Lindab**, good thinking is a philosophy that guides us in everything we do. We have made it our mission to create a healthy indoor climate – and to simplify the construction of sustainable buildings. We do that by designing innovative products and solutions that are easy to use, as well as offering efficient availability and logistics. We are also working on ways to reduce our impact on our environment and climate. We do that by developing methods to produce our solutions using a minimum of energy and natural resources, and by reducing negative effects on the environment. We use steel in our products. It's one of few materials that can be recycled an infinite number of times without losing any of its properties. That means less carbon emissions in nature and less energy wasted.

**We simplify construction**