

# Lindab General information and theory





# We simplify construction

At Lindab we are driven by a strong desire to continuously generate improvements and to simplify construction. We do that by developing products and systems that are easy to use and energy efficient, together with industry-leading knowledge, support, logistics and efficient availability. We want to simplify everything – from designing, ordering, delivery, goal achievement and installation to the entire way of doing business with us. By simplifying in every stage of the construction process, we also contribute to energy-efficiency.

#### A good thinking company

Good thinking is a deeply rooted philosophy that guides us in everything we do. We firmly believe that good thinking makes good solutions to the challenges we all face. Taking responsibility for what we do and how we do things is therefore important to us. Because good thinking is not only about making life easier and more comfortable for our customers and end users. It is also a matter of thinking in a global perspective, all the time. Knowing that we at Lindab are helping to make the world a better place.

# Eurovent certification

Lindab's circular duct system with rubber gasket connections Lindab Safe and Lindab Safe Click is certified to strength and leakage in tightness class D according to the Eurovent Certified Performance program for circular metallic ducts systems (DUCT-MC). Check ongoing validity of certificate:

www.eurovent-certification.com



The purpose of Eurovent third party Certification is to create a common set of criteria to all relevant features for the rating of products in this system and ensure the constancy of performance over time. Through specification of **products in Lindab's certified system, Lindab Safe and Lindab Safe Click**, the engineer's tasks become easier, since there is no need to carry out detailed comparison and performance qualification testing. Consultants, specifiers and users can select products with the assurance that the catalogue data are accurate to a certain level.

Lindab products that are Eurovent certified have the Eurovent logotype in the footer of the technical documentation.

Note: Most Lindab Safe and Lindab Safe Click and the most commonly used product in a ventilation system are essentially better than class D, however some products are according to EN 15727 not class D as a single product. These products are stated in the documentation as Class C and can be used in D class systems to a limited extension.

# lindQST – Lindab Quick Selection Tool

lindQST is an advanced web tool that makes the selection of our solutions quick and simple.

With lindQST all documentation is made available directly on the web. That means consultants, installers and architects always have access to the latest documentation, installation instructions and product images etc. lindQST is a unique online tool were you can simulate your room in the Indoor Climate Designer, keep track of your projects and share it with your business partners etc. lindQST provides a simple shortcut to Lindab's material and is a tool that speeds up and simplifies the daily work. All information is just a mouse-click away.



# Dimensions

The dimension range, measures, colours and ways of how to build the products shown in this catalogue are general and the most frequent ones. Please be aware of that local variations may occur.

### **Designations and examples**

These designations and dimensions of ducts and fittings are adapted to CEN standards.

Lengths are given in mm.

Angles are given in degrees.

Fittings with  $\emptyset d_1 - \emptyset d_4$  fit inside ducts and fittings with  $\emptyset d$ .

Duct and female dimension	Ød
Connector dimension	Ød <sub>1</sub> , Ød <sub>2</sub> , Ød <sub>3</sub> , Ød <sub>4</sub>
Sheet metal thickness	t
Installation length	I, I <sub>1</sub> , I <sub>2</sub> , I <sub>3</sub>



	'm
Insertion length	I
Eccentricity	cc
Component length	L
Circumference	C
Cross-sectional area	A <sub>c</sub>
Mass	m
Linear mass	m









### Tolerances

The measures on this page are principally applicable to our "old" range of products mainly manufactured of sheet metal. The measures cannot unreflectingly be regarded as valid for "any" product e.g. flexible ducts.

### Bold face denotes standard dimensions.

Standard face denotes intermediate dimensions.

### **Ducts**



Fittings



According to EN1506

Ød	Tolerance								
nom	range								
63	63,0	-	63,5						
80	80,0	-	80,5						
100	100,0	-	100,5						
112	112,0	-	112,5						
125	125,0	-	125,5						
140	140,0	-	140,6						
150	150,0	-	150,6						
160	160,0	-	160,6						
180	180,0	-	180,7						
200	200,0	-	200,7						
224	224,0	-	224,8						
250	250,0	-	250,8						
280	280,0	-	280,9						
300	300,0	-	300,9						
315	315,0	-	315,9						
355	355,0	-	356,0						
400	400,0	-	401,0						
450	450,0	-	451,1						
500	500,0	-	501,1						
560	560,0	-	561,2						
600	600,0	-	601,2						
630	630,0	-	631,2						
710	710,0	-	711,5						
800	800,0	-	801,6						
900	900,0	-	902,0						
1000	1000,0	-	1002,0						
1120	1120,0	-	1122,5						
1250	1250,0	-	1252,5						
1400	1400,0	-	1402,8						
1500	1500,0	-	1502,9						
1600	1600.0	_	1603,1						

According to EN1506

Ød <sub>1</sub> , d <sub>2</sub> , d <sub>3</sub> , d <sub>4</sub> nom	Tole ra	erar ango	nce e	l <sub>i</sub> nom
63	61,8	-	62,3	40
80	78,8	-	79,3	40
100	98,8	-	99,3	40
112	110,8	-	111,3	40
125	123,8	-	124,3	40
140	138,7	-	139,3	40
150	148,7	-	149,3	40
160	158,7	-	159,3	40
180	178,6	-	179,3	40
200	198,6	-	199,3	40
224	222,5	-	223,3	40
250	248,5	-	249,3	60
280	278,4	-	279,3	60
300	298,4	-	299,3	60
315	313,4	-	314,3	60
355	353,3	-	354,3	60
400	398,3	-	399,3	80
450	448,2	-	449,3	80
500	498,2	-	499,3	80
560	558,1	-	559,3	80
600	598,1	-	599,3	80
630	628,1	-	629,3	80
710	708,0	-	709,3	100
800	798,0	-	799,3	100
900	897,9	-	899,3	100
1000	997,9	-	999,3	120
1120	1117,8	-	1119,3	120
1250	1247,8	-	1249,3	120
1400	1397,3	-	1398,8	150
1500	1496,9	-	1498,5	150
1600	1596,5	-	1598,2	150

### Length

I, I <sub>1</sub> , I <sub>3</sub> , etc	Tolerance
0–15	+0 -2
16–100	+0 -5
101–	+0 -10
L	±5

# Weight ±10%

### Sheet metal thickness

As in sheet metal standard EN 10143

# Corrosivity classes according to ISO 12944-2 with environmental examples

Corrosivity	Correctivity	Examples of typical environments (informative only)						
category	Corrosivity	Exterior	Interior					
C1	Very low	-	Heated buildings with clean atmosphere, e.g. offices, shops, schools, hotels.					
C2	Low	Atmospheres with low level of pollution: mostly rural areas.	Unheated buildings where condensation can occur, e.g. depots, sports halls.					
C3 Medium		Urban and industrial atmospheres, mode- rate sulfur dioxide pollution; coastal areas with low salinity.	Production rooms with high humidity and some air pollution, e.g. food-processing plants, laundries, breweries, dairies.					
C4	High	Industrial areas and coastal areas with moderate salinity.	Chemical plants, swimming pools, coastal ship and boatyards.					
C5	Very high	Industrial areas with high humidity and aggressive atmosphere and coastal areas with high salinity.	Buildings or areas with almost permanent condensation and with high pollution.					
сх	Extreme	Offshore areas with high salinity and industrial areas with extreme humidity and aggressive atmosphere and subtropical and tropical atmospheres.	Industrial areas with extreme humidity and aggressive atmosphere.					

### Sheet metal quality

#### Galvanized

Fittings and ducts from Lindab Ventilations standard programme are manufactured from zinc coated sheet metal. This means that the base material shall be hot dipped zinc galvanized steel sheet metal with a yield point of approx. 200 N/mm<sup>2</sup>, and that the galvanization shall be minimum as class Z 275. This surface treatment corresponds to the corrosivity category C3.

The following material is used in the standard range:

Ducts and hand made fittings are made with material to EN 10346 – DX51D M-A-C.

Pressed fittings are made with material to EN 10346 – DX54D M-B-C.

#### Stainless steel

Is divided into two grades.

The lowest grad is according to EN 1.4301 (AISI 304) and complies with the requirements for corrosivity class C4.

The higher grad is according to EN 1.4404 (AISI 316L) and complies with the requirements for corrosivity class C5.

Some fitting which are normally pressed are hand made and folded together.

#### Zinc-Magnesium

With surface treatment to ZM 310 means 310 g zincmagnesium/m<sup>2</sup> double sided, which complies with the requirements of corrosivity category C5. Nomally pressed fittings are handmade and folded together.

#### Aluminium-Zinc

With surface treatment to AZ 185 means 185 g aluminiumzinc/m<sup>2</sup> double sided, which complies with the requirements of corrosivity category C4. The sheet metal is treated with Anti-fingerprint, which protects against fingerprints during production and assembly. Nomally pressed fittings are handmade and folded together.

#### Aluminium

To ISO/DIS 209-1. Complies with the re-quirements of corrosivity category C4 without surface coating. Nomally pressed fittings are handmade and folded together.

#### Painted

Products are made, as standard, from hot dip galvanised steel sheet and then powder coated internally and externally with a mixed powder consisting of epoxy and polyester (PE) to a thickness of 80  $\mu$ m.

Painted products as above complies with the requirements of corrosivity category C4. Standard colors are white NCS S0502-Y 30 gloss units and white NCS S1002-G 30 gloss units. The gloss is defined by the Gardner 60° scale. Other colors can be made on request.

**NOTE!** For ducts of  $\emptyset$ <100, the maximum length is 1,5 m for internal coating.

Products can optionally be coated on only the inside or outside.

Powder coating can be optionally obtained in thicknesses of up to 200  $\mu\text{m}.$ 

Products painted with mix powder, epoxy plus polyester, can after some time of exposure to UV radiation receive changes in colour. Hence storage in sunlight ought to be avoided.

#### Thickness of the surface

A surface treatment to class Z 275 is defined in EN 10346 and means 275 g zinc/m<sup>2</sup> double sided. Z 275 thus tells the total amount of zinc on both sides of a 1 m<sup>2</sup> sheet metal plate. The thickness can thus be calculated as

Zinc thickness =  $\frac{\text{zink weight}}{\text{number of sides} \cdot \text{zink density}} = 0.275$ 

 $= \frac{0,275}{2 \cdot 7140} \cdot 10^6 = 19 \ \mu \ m$ 

### Sheet metal thicknesses

The sheet metal thickness tolerances is defined in EN 10143. The thickness of each product is chosen by Lindab to withstand normal use in ventilation, handling on trucks, building places and during mounting of the system. If there is special requirement for thicker material the inner diameter of the ducts will be smaller and special arrangements can be needed.

### Temperature limits for our materials

The shaded cells mark standard design.

The measures on this page are principally applicable to our "old" range of products mainly manufactured of sheet metal.

The measures cannot unreflectingly be regarded as valid for "any" product e.g. flexible ducts.

		Operation						
		Conti	nuous	Intern	nittent			
Product	Material/type		Tempera	ture limit				
		min °C	max °C	min °C	max °C			
	Galvanized steel sheet metal		200 <sup>1</sup>		250 <sup>2</sup>			
	Aluminium sheet metal		200 <sup>3</sup>		300			
Proceed and seem welded	Stainless steel sheet metal		500		700			
Fressed and seam weided	ZincMagnesium sheet metal		100		150			
	PE/EP coated products		80		100			
	Aluzink sheet metal		315					
Swaged, spot welded and/or	Acrylic mastic	-40	70					
blind interlocked joint	Silicone mastic		150		200			
Safe gasket and damper blade	EPDM rubber	-30	100	-50	120			
seals	Silicone rubber	-70	150	-90	200			
Foam rubber seal	EPDM rubber	-30	100	-50	120			
Foam plastic gasket	Polyester	-40	70					
Measuring nozzle	Plastic		70					
Dompor shaft boorings	Polyamide	-30	150	-50	200			
Damper shart bearings	Brass		300					
Dompor actuator	Electric	-30	50					
	Pneumatic	-5	60					
Duct filter	Polyester		100					
Drain hose	Etheylene vinyl acetate and polyethylene	-45	65					
	Glass wool		200					
Insulation	Rock wool		700					
	Rock wool, paper lined		80					
Silencer	Polyester		130		180			

1. Discoloration occurs at about 200 °C in galvanized steel. This is mostly an appearance problem and does not mean impaire corrosion protection in a normal environment.

2. If the temperature rises to about 300 °C, the adhesion of the zinc is impaired, which means poorer corrosion protection.

3. Aluminium sheet will soften after a couple of years at 200 °C.

### Resistance of the Safe system to various substances

The table gives a rough guide to how some of the materials used in the Safe system resist various substances.

Affection	Recommendation	Code
Scarcely affected	Recommended	4
Lightly affected	Normally usable	3
Strongly affected	Only usable in certain cases	2
Badly affected	Unsuitable	1
Information missing		-

				Material	S					Material	6
			EPDM	Silicone	Galvanized				EPDM	Silicone	Galvanized
	Substance	details	rubber	rubber	sheet metal		Substance	details	rubber	rubber	sheet metal
^	Acetaldebyde		1	4	1		Barium sulfide		4		_
~	Acetamide			-	-		Boor		1	1	1
	Acetic	anhydride	3	2	1		Beet sugar liquors		4	-	-
	Acetic acid	30 %	4	3	4		Benzaldehvde		4	_	_
	Acetic acid	10 % 50 %	2	-	-		Benzene benzole		1	1	4
	Acetic acid	25 % 100 °C	- 1	-	-		Benzenesulfonio acid		1	1	4
	Acetic acid	25 %, 100 °C	1	-	-		Benzeie acid		-	-	-
	Acetic acid	onvotallina apotio apid	1	-	4		Benzul alaahal		-	-	-
	Acetic aciu	crystalline acetic aciu	4	3 2	4		Benzyl aconol Benzyl benzeete		3	-	-
	Acetonie		4	3	4		Denzyl benzuale		3	-	-
	Acetonitrile		4	-	-		Benzyl chionae		-	-	-
	Acetoprieriorie		4	-	-		Black liquor		1	_	_
	Acetyl chioride		_	-	_		Black water, waste wate	er	4	3	4
	Acetylene		4	3	4		Blast furnace gas		-	-	-
	Acrylonitrile		1	-	-		Bleach solutions		4	-	-
	Adipic acid		-	-	-		Borax		4	3	4
	Air	70 °C	4	-	-		Bordeaux mixture		4	-	-
	Air	100 °C	4	-	-		Boric acid		4	4	2
	Air	150 °C	3	-	-		Boron fuels		-	-	-
	Air	200 °C	2	-	-		Brake fluid	vegetable, 50 °C	3 4	-	-
	Alkazene		1	-	-		Brine		4	-	-
	Alum		4	4	4		Bromic acid		4	1	1
	Aluminium acetate		4	-	-		Bromide	liquio	– t	1	1
	Aluminium chloride		4	-	-		Bromine	anhydrous	s –	-	-
	Aluminium fluoride		4	-	-		Bromine trifluoride		1	-	-
	Aluminium nitrate		4	4	2		Bromine water		-	-	-
	Aluminium phosphat	e	4	-	-		Bromobenzene		1	-	-
	Aluminium sulfate		4	-	-		Butadiene		2	-	-
	Ammonia	liquid, anhydrous	4	-	-		Butane		1	4	4
	Ammonia gas	cold	4	4	3		Butanol, butyl alcohol	50 °C	2 4	3	4
	Ammonia das	hot	3	3	3		Butanol, butvl alcohol	100 °C	- (	-	-
	Ammonium carbona	te	4	_	_		Butter		4	-	_
	Ammonium chloride		4	_	_		Butter	water free, 100 °C	2	_	-
	Ammonium hydroxid	le	4	3	3		Butyl acetate		3	1	4
	Ammonium nitrate	-	4	3	3		Butyl acetyl ricinoleate		4	_	_
	Ammonium persulfat	te	4	_	_		Butyl acrylate		1	_	-
	Ammonium phospha	ate	4	_	_		Butyl alcohol		3	_	_
	Ammonium sulfate		4	_	_		Butyl amine		1	_	_
			4	1	4		Butyl benzoate		4	_	_
	Amyl alcohol pentar	lol	4	_	_		Butyl carbitol		4	_	_
	Amyl borate		1	_	_		Butyl cellosolve		4	_	_
	Amyl chloronaphtale	ne	1	_	_		Butyl oleate		3	_	_
	Amyl nanhtalene	10	1	_	_		Butyl stearate		3	_	_
	Aniline		3	_	4		Butylaldebyde		3	_	_
	Aniline dve		3	_	4		Butylene		1	_	_
	Aniline bydrochloride	<b>_</b>	3	_	-	c	Calcium acotato		1	_	_
	Animal fate		3	2	4	U	Calcium bioulfite		4	-	-
	Animariais		2	5	4		Calcium oblarida		1	-	-
	Ansul ether		2	-	-		Calcium budravida		4	-	-
	Aquaregia		2	-	-		Calcium hyproxide		4	-	-
	Arsonia acid		2	-	-		Calcium nypochionite		4	-	-
	Aroopio trichlarid		4	4	3				4	3	3
	Arsenic trichloride		_	_	-		Calcium sulfide		4	-	-
	Aspnait		1	1	I		Cane sugar liquors		4	-	-
	Astm oll	No 1	1	-	-		Carbamate		3	-	-
	Astm oil	No 2	1	-	-		Carbitol		3	-	-
-	Astm oil	No 3	1	-	-		Carbolic acid, phenol		3	-	-
в	Barium chloride		4	-	-		Carbon acid		4	-	-
	Barium hydroxide		4	-	-		Carbon bisulfide		1	-	-
	Barium sulfate		4	4	3		Carbon dioxide		3	-	-

			EPDM	Materials Silicone	Galvanized			E	PDM	Materials Silicone	Galvanized
	Substance	details	rubber	lupper	Sheet metai		Substance	details	ubber	lupper	Sheet metai
							<b>D</b> "				
	Carbon monoxide		4	-	-		Dilsopropyi ketone		4	_	-
	Carbon tetrachloride		1	-	-		Dilutin, white spirit		1	1	4
	Castor oil		3	-	-		Dimethyl aniline		3	-	-
	Cellosolve acetate		3	-	4		Dimethyl formamide, DMF		3	-	-
	Cellosolve, ethylene glycol		3	-	4		Dimethyl phtalate		3	-	-
	Chlorine	dry	2	-	1		Dinitrotoluene		1	-	-
	Chlorine	wet	2	-	1		Dioctyl phtalate		3	-	-
	Chlorine dioxide		2	-	-		Dioctyl sebacate		3	-	-
	Chlorine trifluoride		1	-	-		Dioxalane		3	-	-
	Chloro 1-nitroethane		1	-	-		Dioxane		3	-	-
	Chloroacetic acid		3	-	-		Dipentene		1	-	-
	Chloroacetone		4	-	-		Diphenyl oxides		4	-	-
	Chloroacetone acid		3	-	-		Diphenyl, biphenyl		1	-	-
	Chlorobenzene		1	-	_		Dry cleaning fluids		1	-	_
	Chlorobromomethane		3	_	-	F	Epichlorohydrin		3	_	_
	Chlorobutadiene		1	_	_	-	Ethane		1	_	4
	Chlorododecane		1	_	_		Ethanolamino		2		4
	Chloroform			-	-				3	-	-
	Chlorotottiii		-	-	-		Elliyi acelale		3	2	4
	Chloronapthalene		1	-	-		Ethylacetoacetate		3	-	-
	Chloroprene		1	_	_		Ethyl acrylate		3	-	-
	Chlorosulfonic acid		1	1	1		Ethyl alcohol		4	4	4
	Chlorotoluene		1	-	-		Ethyl benzene		1	-	-
	Chrome plating solutions		1	-	-		Ethyl benzoate		3	-	-
	Chromic acid		2	2	1		Ethyl cellosolve		3	-	-
	Chromic acid	10 %, 50 °C	1	-	-		Ethyl cellulose		3	-	-
	Citric acid		4	4	3		Ethyl chloride		4	1	-
	Cobalt chloride		4	-	-		Ethyl chlorocarbonate		-	-	-
	Cocoanut oil		4	-	-		Ethyl chloroformate		_	_	-
	Cod liver oil		4	-	_		Ethyl ether		2	-	4
	Coke oven gas		1	_	_		Ethyl formate		3	_	_
	Copper acetate		4	_	_		Ethyl alycol cellosolye		3	_	4
	Copper chloride		4	4	1		Ethyl mercantan		1	_	-
	Copper evanide		4	4	1		Ethyl ovalata		1	-	-
			4	-	-				4	-	-
			4	-	-		Ethyl pentochlorobenzene		1	-	-
			2	-	-		Ethyl silicate		4	-	-
	Cottonseed oil		4	-	-		Ethylene		-	-	-
	Creosote		1	-	-		Ethylene chloride		2	-	-
	Cresol		1	-	-		Ethylene chlorohydrin		-	-	-
	Cresylic acid		1	-	-		Ethylene diamine		4	-	-
	Cumene		-	-	-		Ethylene dichloride		2	-	-
	Cyclohexane		1	-	-		Ethylene glycol		4	3	4
	Cyclohexanol		1	-	-		Ethylene oxide		2	-	-
	Cyclohexanone		3	-	-		Ethylene trichloride		2	-	-
D	Decalin		-	-	-	F	Fatty acids		1	-	-
	Decane		_	-	_		Ferric chloride		4	-	-
	Denatured alcohol		4	-	_		Ferric nitrate		4	-	-
	Detergent solutions		4	4	3		Ferric sulfate		4	-	_
	Developing fluids		3	_	4		Fish oil		_	_	-
	Diacetone		4	_	_		Eluoric silicate		4	2	2
	Diacetone alcohol		4	_	_		Eluorinated cyclic ethers		4	_	_
	Dibenzyl ether		3	_	_		Fluorine	liquid	2	_	_
	Dibenzyl sobacato		3	_	_		Fluorobonzono	iquiu	1	_	_
	Dibutyl amina		1	_	_		Fluereberia apid		1	_	_
	Dibutyl ather		1	-	-		Fluoroboric acid		4	-	-
	Dibutyl etner		2	-	-		Fluorocarbonolis		4	-	-
	Dibutyl phtalate		4	-	-		Fluorochloroethylene		-	-	-
	Dibutyl sebacate		3	-	-		Fluorosilic acid		-	-	-
	Dichloro isopropyl ether		2	-	-		Formaldehyde, formalin	40 %	4	-	4
	Dichlorobenzene		1	-	-		Formaldehyde, formalin	40 %, 70 °C	-	-	-
	Dicyclohexylamine		1	-	-		Formic acid		4	2	-
	Diesel oil		1	2	4		Formic acid	70 °C	3	-	3
	Diester oil, fluid 101		-	-	-		Freon	11	1	1	4
	Diethyl benzene		1	-	-		Freon	12	3	1	4
	Diethyl ether		1	-	_		Freon	13	4	-	4
	Diethylamine		3	_	_		Freon	13 B 1	4	_	_
	Diethylbenzene		1	_	_		Freon	21	1	_	4
	Diethylene alvool		4	_	_		Freon	21	4	- 1	- 1
	Diathyleabaaata		4	-	-		Freen	22	+ 1	I	ч л
	Disobutylogo		5	-	-		Froop	31	4	-	4
			-	-	-		From	32	4	-	4
			1	-	-			112	1	-	4
	Disopropyl etner		1	-	-		FIEON	113	1	1	4

--3

--4

-

-2

-

-4

-

-

-

-4

-4

---4

--1

--2 2

---1

-4 ----

\_

EPDM rubber

-

Silicone Galvanized

rubber sheet metal

--3

------------4

-

\_

-

\_

\_

\_

\_

-

\_ \_

\_

\_

--4

-4 -4 4

---4

-4 -----

			Material	s			
		EPDM	Silicone	Galvanized			
	Substance details	rubber	rubber	sheet metal		Substance	details
	Freon 114	4	1	4		lodine pentafluoride	
	Freon 114 B 2	1	-	_		lodoform	
	Freon 115	4	-	4		Iron salts	non-oxidizing
	Freen 142 b	4	-	-		Isoamyl alcohol	
	Freon 218	4	_	_		Isoforon	
	Freon 502	_	_	_		Isooctane, fuel A	
	Freon BF	_	-	_		Isooctane/toulene, fuel B a	nd C
	Freon C 316	4	-	-		Isopropyl acetate	
	Freon C 318	4	-	-		Isopropyl alcohol	
	Freon MF	-	-	-		Isopropyl chloride	
	Freon TA	4	-	-		Isopropyl ether	
	Freon TC	3	-	-		Isopropyl nitrate	
	Freen IF	1	-	-	ĸ	Kerosene	
	Freen TP35	3	-	-	L	Lacquer solvents	
	Freen T-WD 602	3	_	_		Lacquers Lactic acid	
	Fuel B 70 % isooctane 30 % toulene	1	_	_		Lactic acid	
	Fuel C 50 % isooctane, 50 % toulene	1	-	_		Lavender oil	
	Fuel oil, bunker oil, diesel oil	1	-	_		Lead acetate	
	Fuel oil, bunker oil, diesel oil 70 °C	1	-	-		Lead nitrate	
	Fumaric acid	-	-	-		Lead sulfamate	
	Furan, furfuran	2	-	4		Lime bleach	
	Furfural	3	-	4		Lime sulfur	
G	Gallic acid	3	-	-		Linoleic acid	
	Gasohol 50 % toulene,					Linseed oil	
	30 % Isooctane,	1				Liquid manure	\
	Gasoline	1	_	_			)
	Gelatine	4	_	_	м	Magnesium chloride	
	Glaubers salt	3	-	_		Magnesium hydroxide	
	Glucose	4	4	4		Magnesium sulfate	
	Glycerin	4	4	4		Maleic acid	
	Glycerol, glycerine	4	-	-		Maleic anhydride	
	Glycolmonoethylether, cellosolve	3	-	-		Malic acid	
	Glycolmonoethyletheracetate,					Manganese salts	non-oxidizing
	cellosolveacetate	4	-	-		Mercuric chloride	
	Glycolmonoethyletherbutyl, butylcellosolve	e 4	-	-		Mercury	
	Giycols	4	-	-		Mercury sails	non-oxidizing
н	Halowax oil	1	-	-		Methacrylacidmethylester	125 °C
••	Heating oil	1	2	4		Methane	120 0
	Heptane	1	_	_		Methyl acetate	
	Hexachlorobutadiene	1	-	-		Methyl acrylate	
	Hexaldehyde	4	-	-		Methyl alcohol, methanol, v	wood alcohol
	Hexane	1	-	-		Methyl bromide	
	Hexene	1	-	-		Methyl butyl keton	
	Hexyl alcohol, hexanol	2	-	_		Methyl cellosolve	
	Hydraulic oil mineral oil based	1	3	4		Methyl chloride	
	Hydraulic oli phosphale ester based	4	4	4		Methyl cyclopentane Methyl ethyl ketone MEK	
	Hydrochloric acid dilute	4	1	_		Methyl formate	
	Hydrochloric acid 37 %	4	1	2		Methyl glycol acetate	50 °C
	Hydrochloric acid 37 %, 70 °C	2	1	_		Methyl isobutyl ketone	
	Hydrochloric acid 10 %, 100 °C	1	-	-		Methyl isopropyl ketone	
	Hydrocyanic acid	4	-	-		Methyl methacrylate	
	Hydrofluoric acid anhydrous	2	-	-		Methyl oleate	
	Hydrofluoric acid concentrated, cold	3	1	2		Methyl salicylate	
	Hydrofluoric acid concentrated, hot	1	1	1		Methylacrylic acid	
	Hydrofluorosilic acid	4	1	2		Methylene chloride	
	nyurugen gas	4	4	4		wethylene alchioride	
	Hydrogen peroxide 30 %	4 1	4 1	4 1		Mineral oil	
	Hydrogen peroxide 30 %, 20 C	2	4 4	-+ 		Monobromobenzene	
	Hydrogen sulphide drv	4	4	3		Monochlorobenzene	
	Hydrogen sulphide damp	4	2	-		Monoethanolamine	
	Hydrogen sulphide damp, hot	3	1	-		Monomethyl aniline	
	Hydroquinone	-	-	-		Monomethylether	
	Hypochlorus acid	3	-	-		Monovinyl acetylene	
1	lodine	-	-	3		Mustard gas	

			EDDM	Silicone	Galvanized				EDDM	Silicone	Galvanized
			rubber	rubber	sheet metal				rubber	rubber	sheet metal
	Substance	details					Substance	details			
N	Naphta		1	_	_		Potassium hydroxide		4	3	2
	Naphtalene		1	_	_		Potassium hypochlorite pH 7	below 10 a/	4	1	4
	Naphtenic acid		1	_	_		Potassium hypochlorite	over 10 g/	3	1	4
	Natural gas		1	4	4		Potassium nitrate	616. To g,	4	_	_
	Nickel acetate		4	_	_		Potassium permanganate	25 %, 70 °C	; 1	-	_
	Nickel chloride		4	_	-		Potassium sulfate		4	3	4
	Nickel sulfate		4	-	-		Producer gas		1	-	-
	Nitric acid	20 %	4	-	2		Propane/butane, LPG		1	1	4
	Nitric acid 20	0 %, 50 °C	3	1	-		Propyl acetate		3	-	-
	Nitric acid 40	0 %, 50 °C	3	1	-		Propyl alcohol, propanol		4	4	4
	Nitric acid 50	0 %, 50 °C	2	1	-		Propyl amine		2	-	-
	Nitric acid	60 %	2	1	-		Propyl nitrate, isopropyl nitra	te	3	-	-
	Nitric acid	70 %	1	1	-		Propylene oxide		3	-	-
	Nitric acid	red fuming	1	1	-		Propylene, propene		1	-	-
	Nitrobenzene		3	1	4		Pydraul F–9, phosphate este	r 80 °C	; 3	-	-
	Nitrobenzine		2	-	-		Pyridine		3	-	-
	Nitroethane		3	-	-		Pyroligneuos acid		3	-	-
	Nitrogen		4	4	4		Pyrrole		2	-	-
	Nitrogen		4	-	-	R	Radiation		3	2	4
	Nitrogentetroxide		2	-	-		Rapeseed oil, canola oil		4	4	4
	Nitrogentetroxide		2	-	-		Rapeseed oil, canola oil	100 °C	3	-	-
	Nitromethane		3	-	-		Rosin oil		1	1	4
	Nitropropane		4	-	-	S	Sal ammoniac		4	-	-
	Nitrous gases		2	2	4		Salicylic acid		4	4	4
0	Octachlorotoluene		1	-	-		Salt water		4	-	-
	Octadecane		1	-	-		Salts (inorganic) and salt solu	itions			
	Octane		1	-	-		sat	turated, 70 °C	; 4	-	-
	Octanol		4	-	-		Sewage		3	-	-
	Octyl alcohol		4	-	-		Silicate esters		1	-	-
	Oleic acid		3	-	4		Silicone greases		4	-	-
	Oleum spirits		-	-	-		Silicone oils		4	-	-
	Olive oil		3	3	4		Silver nitrate		4	-	-
	Oxalic acid		4	3	1		Skydrol 500		4	-	-
	Oxidizing salt solution (KMnO4)2	25 %, 70 °C	) 1	-	-		Skydrol 7000		4	-	-
	Oxygen	cold	4	4	4		Soap solutions		4	-	-
	Oxygen	90–200 °C	1	-	-		Soda ash		4	-	-
	Ozone		4	4	2		Sodium acetale		4	-	-
Ρ	Palmitic acid		3	-	4		Sodium bicarbonate		4	-	-
	Paraffine, kerosine		1	1	4		Sodium bisulfite		4	-	-
	p-Cymene		1	-	-		Sodium borate		4	-	-
	Peanut oil		2	-	-		Sodium carbonate	20 %, 100 °C	4	-	-
	Pentanol, amyl alcohol		4	-	-		Sodium chloride		4	-	-
	Perchloric acid		3	1	1		Sodium cyanide		4	-	-
	Perchloroethylene		1	3	4		Sodium hydroxide, sodium h	ydrate,			
	Petroleum oils		1	1	4		caustic soda		4	2	1
	Petroleum, petrol		1	1	4		Sodium hypochlorite max	< 10 g/l free C	4	-	4
	Phelyn hydrazine		2	-	-		Sodium hypochlorite over	r 10 g/l free C	13	-	4
	Phenol		3	2	2		Sodium metaphosphate		4	-	-
	Phenyl ethyl ether		1	-	-		Sodium nitrate		4	4	3
	Phenyl hydrazine		3	-	-		Sodium perborate		4	-	-
	Phenylbenzene		1	-	-		Sodium peroxide		4	-	-
	Phorone Dhaan havia a sid	00.0/	3	-	-		Sodium phosphate		4	-	-
	Phosphoric acid	20 %	4	_	-				4	-	-
	Phosphoric acid	45 %	3		2		Sodium suitate		4	-	-
	Phosphoric acid	85 %	4	I	I				4	-	-
	Phosphoric acid 60	0%,50°C	4	-	-		Soybean oll		2	-	-
	Phosphorus trichloride		4	-	-		Stannicous chioride		3	-	-
			3	-	-		Steam	under 150°C	, 4	-	-
	Fille Oll Dinono		1	-	-		Steam and	over 150 °C	, J ,	-	-
	Finelie Diporidipo		1	-	-		Steand adlu		ა 1	-	-
		0.000	1	-	-		Suprese estation		1	1	4
		chrome	4	-	-		Sucrose solution		4	4	4
		others	4	3	-				ۍ ۸	_	-
	Potopoium apatata		4	-	-		Sulfur obleride		4	4	4
	Potassium acetate		4	-	-				I	-	2
			3	-	-				_	-	-
	Potassium oupro overido		4	-	-				4	ა	3
	Potassium ovanida		4 1	_	_		Sulfur triovide		4	- 0	- 0
	Potassium dicromate			_	_		Sulfuric acid	10 % 100 %	3	<u>د</u>	<u> </u>
	i olassium uloiomale		4	-	-		oununo aolu	10 /0, 100 0	. 4	-	-

				Materials	6
			EPDM	Silicone	Galvanized
			rubber	rubber	sheet metal
	Substance	details			
	Sulfurous acid		3	1	3
	Sulphuric acid	60 %,	4	1	2
	Sulphuric acid	60 %, 50 °C	4	1	-
	Sulphuric acid	60–75 %, 50 °C	3	1	-
	Sulphuric acid	75-80 %, 50 °C	2	1	-
	Sulphuric acid	85-96 %, 50 °C	1	1	-
	Sulphuric acid	fuming, Oleum	1	1	-
т	Tannic acid		4	1	4
	Tar	bituminous	1	2	1
	Tartaric acid		3	_	-
	Terpineol		2	_	_
	Tertiarv butvl alcohol		3	_	_
	Tertiary butyl catechol		3	_	_
	Tertiary butyl mercaptan		1	_	_
	Tetrabromomethane		1	_	_
	Tetrabutyl titanate		4	_	_
	Tetrachloroethane		_	_	_
	Tetrachloroethylene		1	_	_
	Tetraethyl lead		1	_	_
	Totrabydrofuran THE		2	_	_
	Totralin		1	-	-
	Thinner			-	-
	Thiopyloblorida		1	-	-
	Thionyl chionde		1	-	-
			1	-	-
	Toluene dilsocyanate		4	_	_
	Toluene, toluol		1	1	4
	Iransformer oli chiorat	ed nydrocarbon	1	1	4
	Iransformer oll r	nineral oil based	1	3	4
	Iransmission fluid type a		1	-	-
			4	-	-
	Iriaryi phosphate		4	-	-
	Iributoxy ethyl phosphate		4	-	-
	Iributyl mercaptan		1	-	-
	Tributyl phosphate		4	-	_
	Trichloretane, thinner		1	2	4
	Trichloroacetic acid		3	-	-
	Trichloroethylene		1	-	-
	Tricresyl phosphate		4	-	-
	Triethanol amine		3	-	-
	Triethyl amine		1	-	-
	Triethyl borane	70 °C	2	-	-
	Trinitrotoluene		1	-	-
	Trioctyl phosphate		4	-	-
	Tung oil		1	-	-
	Turbine oil		1	-	-
	Turpentine		1	1	4
v	Vegetable oils		3	4	4
	Vinyl chloride		3	-	-
w	Water	distilled	4	4	4
	Water	fresh	4	4	4
	Water fresh and	distilled, 100 °C	4	2	4
	Water	salt	4	4	2
	White liquor		4	3	-
	White spirit, dilutin		1	1	4
	Wine		4	4	4
Х	Xylene, xylol		1	1	4
z	Zinc salts	non-oxidizing	4	4	4

### Units

The SI system (Système International d'Unités) is used in this catalogue, in accordance with international practice. Units may be given in the "technical system" in diagrams and tables, in parallel with the SI system.

### Some basic units

For length	metre	m
For mass	kilogramme	kg
For time	second	s
For electric current	ampere	А
For temperature	kelvin	Κ

### Some derived units

For frequency	hertz	Hz	1 Hz	= 1/s
For force	newton	Ν	1 N	= 1 kg $\cdot$ m/s <sup>2</sup>
For pressure,				
mechanical stress	pascal	Ра	1 Pa	= 1 N/m <sup>2</sup>

For energy, work	joule	J	1 J	= 1 N · m
For power	watt	W	1 W	= 1 J/s
For electric potential, electric tension	volt	V	1 V	= 1 W/A

### Some additional units

For time	minute	min	1 min	= 60 s
	hour	h	1 h	= 3 600 s = 60 min
For flat angles	degree	0	1°	= 1/360 of a circle
For volume	litre	I	11	$= 1 \ 000 \ cm^3 = 1 \ dm^3$

### Some multiple prefixes

Index	Designation	Des.	Example	
10 <sup>12</sup>	tera	Т	1 terajoule	1 TJ
10 <sup>9</sup>	giga	G	1 gigawatt	1 GW
10 <sup>6</sup>	mega	М	1 megavolt	1 MV
10 <sup>3</sup>	kilo	k	1 kilometre	1 km
10 <sup>2</sup>	hecto	h	1 hectogramme	1 hg
10 <sup>1</sup>	deca	da	1 decalumen	1 dalm
10 <sup>-1</sup>	deci	d	1 decimetre	1 dm
10 <sup>-2</sup>	centi	С	1 centimetre	1 cm
10 <sup>-3</sup>	milli	m	1 milligramme	1 mg
10 <sup>-6</sup>	micro	μ	1 micrometre	1 µm
10 <sup>-9</sup>	nano	n	1 nanohenry	1 nH
10 <sup>-12</sup>	pico	р	1 picofarad	1 pF

### **Conversion factors**

Tables for conversion to other dimensions are given for some of the units commonly used in the industry.

Pressure, p					
Pa pascal N/m²	mm wc mm Aq mm H <sub>2</sub> O	mm Hg (at 20 °C)	in wg " wg in wc	psi(g) ibf/in²	bar
1	0,102	0,007 53	0,004 02	0,000 145	0,000 010 0
9,79	1	0,073 7	0,039 4	0,001 42	0,000 097 9
133	13,6	1	0,534	0,019 3	0,001 33
249	25,4	1,87	1	0,036 1	0,002 49
6 895	704	51,9	27,7	1	0,068 9
100 000	10 215	753	402	14,5	1

### Length, I

in inch	ft foot	yd yard	m metre	mile
1	0,083 3	0,027 8	0,025 4	0,000 015 8
12,0	1	0,333	0,305	0,000 189
36,0	3,00	1	0,914	0,000 568
39,4	3,28	1,09	1	0,000 621
63 360	5 280	1 760	1 609	1

### Area, A

in <sup>2</sup>	ft²	yd²	m²		ha
sq in	sq ft	sq yd	sq metre	ar	hectare
1	0,006 94	0,000 772	0,000 645	0,000 006 45	0,000 000 064 5
144	1	0,111	0,092 9	0,000 929	0,000 009 29
1 296	9,00	1	0,836	0,008 36	0,000 083 6
1 550	10,8	1,20	1	0,010 0	0,000 100
155 000	1 076	120	100	1	0,010 0
15 500 031	107 639	11 960	10 000	100	1

### Volume, V

in³ cu in	l litre	US gal gallon	UK gal gallon	ft³ cu ft	yd³ cu yd	m <sup>3</sup> cubic metre
1	0,016 4	0,004 33	0,003 60	0,000 579	0,000 021 4	0,000 016 4
61,0	1	0,264	0,220	0,035 3	0,001 31	0,001 00
231	3,79	1	0,833	0,134	0,004 95	0,003 79
277	4,55	1,20	1	0,161	0,005 95	0,004 55
1 728	28,3	7,48	6,23	1	0,037 0	0,028 3
46 656	765	202	168	27,0	1	0,765
61 024	1 000	264	220	35,3	1,31	1

### Velocity, v

ft/min fnm	km/h Bz	ft/s	mile/h mph	knot kn	m/s
1	0.019.2	0.016.7	0.011.4	0.000.97	0.005.09
1	0,018 3	0,0107	0,011 4	0,009 87	0,005 08
54,7	1	0,911	0,621	0,540	0,278
60,0	1,10	1	0,682	0,592	0,305
88,0	1,61	1,47	1	0,869	0,447
101	1,85	1,69	1,15	1	0,514
197	3,60	3,28	2,24	1,94	1

### Volume flow, $q_v$

ft³/h			ft³/min		
cfh	l/min	m³/h	cfm	l/s	m³/s
1	0,472	0,028 3	0,016 7	0,007 87	0,000 007 87
2,12	1	0,060 0	0,035 3	0,016 7	0,000 016 7
35,3	16,7	1	0,589	0,278	0,000 278
60,0	28,3	1,70	1	0,472	0,000 472
127	60,0	3,60	2,12	1	0,001 00
127 133	60 000	3 600	2 119	1 000	1

#### Mass, m

oz	lb nound	kg kilogrammo
ounce	pound	Kilograffille
1	0,062 5	0,028 3
16,0	1	0,454
35,3	2,20	1

### Mass flow, q<sub>m</sub>

lb/min	kg/s
1	0,007 56
132	1

### Density, $\rho$

kg/m³	lb/ft <sup>3</sup>	g/cm³	lb/in <sup>3</sup>
1	0,062 4	0,001 00	0,000 036 1
16,0	1	0,016 0	0,000 579
1 000	62,4	1	0,036 1
27 680	1 728	27,7	1

#### Force, F

N newton	lbf pound-force	kp kilopond
1	0,225	0,102
4,45	1	0,454
9,81	2,20	1

#### Torque, M

lbf ∙ in	Nm	lbf ∙ ft	kpm
1	0,113	0,083 3	0,011 5
8,85	1	0,738	0,102
12,0	1,36	1	0,138
86,8	9,81	7,23	1

### Energy, work, E

J joule Nm, Ws	Btu British thermal unit	kcal kilocalorie	kWh
1	0,000 948	0,000 239	0,000 000 278
1 055	1	0,252	0,000 293
4 187	3,97	1	0,001 16
3 600 000	3 412	860	1

### Power, P

Dtr.//s	W watt	las sl <i>i</i> te	hk metric	hp UK, US
Btu/h	NM/S, J/S	kcal/h	norsepower	norsepower
1	0,293	0,252	0,000 398	0,000 393
3,41	1	0,860	0,001 36	0,001 34
3,97	1,16	1	0,001 58	0,001 56
2 510	735	632	1	0,986
2 544	746	641	1,01	1

### Temperature difference, temperature change, ${\it \Delta T}$ for K; ${\it \Delta 9}$ for °C

К	°F	°C
kelvin	degree Fahrenheit	degree Celsius
1	1,80	1,00
0,556	1	0,556
1,00	1,80	1

### Associated temperatures

K	°F	°C	Physical state
0,00	-460	-273	Absolute zero
255	0,00	-17,8	Mixture of sal ammoniac and snow
273	32,0	0,00	Melting point of ice
293	68,0	20,0	Standard atmospheric temperature
311	100	37,8	Normal temperature of human body
373	212	100	Boiling point of water

### **Conversion between temperatures**

°C = (°F - 32) × 5/9 °C = K - 273,15 °F = °C × 9/5 + 32 K = °C + 273,15

### **Greek letters**

Greek letters are used in technical and scientific texts to de note physical units. Minor variations in the shapes of the letters can be tolerated, on condition that this does not cause any risk of confusion.

Name	Lower case	Upper case
alfa	α	А
beta	β	В
gamma	γ	Г
delta	δ	Δ
epsilon	3	Е
zeta	ζ	Z
eta	η	Н
teta	е	Θ
jota	l	Ι
kappa	к	K
lambda	λ	Λ
my	μ	М
ny	ν	N
ksi	٤	Ξ
omikron	0	0
pi	π	П
ro	ρ	Р
sigma	σ	Σ
tau	τ	Т
ypsilon	υ	Y
fi	φ	Φ
ki	χ	Х
psi	Ψ	Ψ
omega	ω	Ω

# Total pressure = dynamic pressure + static pressure

**The static pressure** in the atmosphere varies with the weather - high pressure or low pressure - and with the height above sea level. The standard pressure, atmospheric pressure at sea level is:

101,3 kPa = 1,013 bar = 1013 mbar

```
(= 1 atm = 760 mm Hg)
```



At one particular point, such as in a ventilation duct, the static pressure comes from all sides.

In a ventilation system, the static pressure is related to the ambient atmospheric pressure outside the duct system; the static pressure can thus be positive - higher than ambient atmospheric, or negative - lower than ambient atmospheric pressure.



### Pressure drop

If you produce a static pressure difference in an open duct system, you can get the air to flow from a point of higher pressure to a point of lower pressure - from the atmosphere via the inlet grating to the suction side of the fan, and from the supply side of the fan via the supply terminals back to the atmosphere. The pressure difference is converted into kinetic energy.



Dynamic pressure is a measure of the kinetic energy of the moving air. The connection between pressure and energy is easy to see if you use SI system units

 $Pa = N/m^2 = Nm/m^3 = J/m^3$  i.e. energy (in J) per unit volume (in m<sup>3</sup>) of the flowing air.

The dynamic pressure depends on

$$P_d = \rho \cdot \frac{\overline{v}^2}{2}$$
 with the units

$$\frac{\mathrm{kg}}{\mathrm{m}^3} \cdot \left(\frac{\mathrm{m}}{\mathrm{s}}\right)^2 = \frac{\mathrm{kg}}{\mathrm{m}^3} \cdot \frac{\mathrm{m}^2}{\mathrm{s}^2} = \frac{\mathrm{kgm}}{\mathrm{s}^2} \cdot \frac{\mathrm{m}}{\mathrm{m}^3} = \mathrm{N} \cdot \frac{1}{\mathrm{m}^2} = \frac{\mathrm{N}}{\mathrm{m}^2} = \mathrm{Pa}$$

Flow in a duct system is normally not free of loss. Friction losses occur and the air is forced to change direction. It requires pressure (i.e. energy) to manage both dynamic and static pressure - the sum of these two is referred to as total pressure.

$$p_t = p_s + p_d$$



Since ps will be negative in relation to atmospheric pressure (on the suction side of the fan), this means that pt will also be negative if the total of  $p_s$  and  $p_d$  is negative.



#### Pressure drop and flow losses

In a ventilation system, you want to get air moving! Clean air is to be supplied to the occupancy zone and polluted air must leave the room, process or machine. Energy is needed to move the air, which is added via the fan, which gets the air moving.

In order to flow through a duct system, air has to overcome two types of flow resistances or pressure drops:

- friction loss between the flowing air and the duct walls.
- single loss when the air changes direction or speed.

Friction loss (also known as the R value) is expressed in the unit Pa/m  $\Delta p_f = \frac{\lambda}{d_h} \cdot \rho \frac{\overline{v}^2}{2}$ 

 $\Delta p_f$  = friction loss per metre (Pa/m).

 $\lambda$  = friction factor related to duct material and surface roughness.

d<sub>h</sub> = hydraulic diameter of the duct, the diameter of a circular duct which gives the same friction pressure drop at the same flow velocity as a rectangular duct.

$$d_h = \frac{2 \cdot a \cdot b}{a + b}$$

where a and b are duct sides.

For a circular duct, d<sub>h</sub> = d

 $\rho$  = air density (kg/m<sup>3</sup>)

 $\overline{v}$  = average velocity of the air (m/s)

•

graphs below.

(3) (4

2

### Pressure drop calculation

#### Fan pressure capacity required

Let us do a pressure drop calculation for a simple duct system!

- Number the fittings, in the direction of air flow.
- Then put the dimension and data of • each component in a table as in the example.

for each component. You can follow this example from the reduced scale



6

No	Flow I/s	Component Denom.	Dimension Ø mm	Length m	Pressure drop Pa/m	Pressure drop Pa
1	400	RCU	315-250	-	-	8,2
2	"	SR	250	2,0	3,3	6,6
3	"	BU 90°	250	-	-	11,0
4	"	SR	250	1,6	3,3	5,3
5	"	SLCU 100	250/1200	1,2	5,0	6,0
6	"	RCFU	250-200	-	-	22,0
$\overline{7}$	"	SR	200	1,5	8,0	12,0
8	"	BU 90°	200	-	-	24,0
9	"	SR	200	1,2	8,0	9,6
(10)	н	RCU	250-200	-	-	15,0
(11)	II	SR	250	3,5	3,3	11,6
(12)	II	RCFU	400-250	-	-	16,0
13	II	HF	400	-	-	14,0
		Total pressure	e drop (sum o	f rows	1 – 13) =	161,3

Add up the pressure drops on the far right of the table.

Then select a suitable fan which gives the required flow q = 400 l/s and a total pressure rise of  $p_t = 161$  Pa.



We reserve the right to make changes without prior notice

### Prerequisites

In order to correctly dimension a duct system you need information about the total pressure drops of the fittings.

The total pressure drop  $\Delta$  pt (Pa) between two sections, 1 and 2, in a duct system is defined by

 $p_t = p_{t1} - p_{t2} = (p_{s1} + p_{d1}) - (p_{s2} + p_{d2})$ 





Section 2

where 
$$p_d = \frac{p \cdot \overline{v}^2}{2}$$
 and  $\overline{v}^2 = \frac{q}{a_c}$ 

It is assumed in pressure drop calculation of ventilation ducts that:

- incompressible flow, i.e. air density does not change.
- isothermal relationship, i.e. no exchange of heat between the duct and its surroundings occurs.
- no changes in potential energy, i.e. height differences between the various sections of the duct system are neglected.

### **Designations used**

I	= length	m (mm)
а	= long side	m (mm)
b	= short side	m (mm)
r	= radius	m (mm)
d	= diameter	m (mm)
d <sub>h</sub>	= hydraulic diameter	m (mm)
A <sub>c</sub>	= cross sectional area	m²
РА	= atmospheric pressure	mbar
p <sub>s</sub>	= static pressure	Pa
р <sub>d</sub>	= dynamic pressure	Pa
p <sub>t</sub>	= total pressure	Pa
$\Delta p$	= pressure drop	Pa
$\Delta p_t$	= total pressure drop	Pa
θ	= temperature	°C
$\overline{v}$	= air velocity (average)	m/s
q	= air flow	m³/s
ρ	= density	kg/m³
α	= angle	0
φ	= relative humidity	%
λ	= friction number	
R	= coefficient of friction	Pa/m
ζ	= resistance number	
ν	= kinematic viscosity	m²/s

The total pressure drops for the most common fittings are shown in graphs, as a function of air flow (or velocity in some cases).

The basic data for the graphs comes from measurements and calculations done at our laboratories. Some graphs are taken from litterature.

The graphs apply to air under standard conditions.

ν	= 15,1 · 10-6 m²/s
θ	= 20 °C
ρ	= 1,2 kg/m <sup>3</sup>
φ	= 65 %
р <sub>А</sub>	= 1013,2 mbar

For air of other density ( $\rho_{other}$ ) the flow ( $q_{other\_density}$ ) is obtained from the formula.

$$q_{other\_density} = q_{graph} \cdot \sqrt{\frac{1,2}{\rho_{other}}}$$

### Ventilation does not have to be noisy!

If you use your common sense, and construct your air treatment system with consideration and good components, you can often avoid problems and complaints.

Fans make noise, this is something you can not do a lot about. But you can prevent the noise from getting into the areas connected to the fan system - you can absorb and damp the noise on the way.

This description does not claim to teach you how to calculate and attenuate noise in a ventilation system - there are books available on this.

#### Source

Waves on water

We throw a stone onto completely calm water.



*Waves in air* We fire a starter's gun.



This description only aims at providing information about a few simple rules and hints, which together with common sence can be enough for simple installations.

You must have some basic knowledge about how and where noise is generated, transmitted and attenuated in the system, to be table to choose the correct principle and correct components. To take a simple analogy: noise transmission consists of waves in a medium, i.e. air, which we can not see. This is very similar to the way waves spread on water.

Let us examine the analogy, to make the comparison clearer:

#### Distribution

Waves on water

Waves on water spread out in increasing concentric circles from the centre, where the stone hit the water.



#### Waves in air

Sound waves spread out in the air, in all directions, in an increasing ball from the centre, i.e. the gun.



#### **Energy transport**

Waves on water

Kinetic energy is transmitted from molecule to molecule in the water. They bounce against each other. Molecules move back and forwards. Energy spreads from the source.

Waves in air

Kinetic energy is transmitted from molecule to molecule in the air. They bounce against each other, and move back and forwards. Energy spreads from the source.



### Distance

Waves on water

When waves depart from the centre, where the stone hit, the wave height becomes lower and lower, until they are invisible. The water is calm again.

#### Waves in air

When sound waves depart from the source, the starter's gun, wave movement drops off and the sound becomes weaker and weaker until it can no longer be heard.



### 

Waves on water

The energy which started the wave propagation, or the power needed to keep it going, is distributed across an increasing area as the distance, the radius, increases.

#### Waves in air

The energy which started the wave propagation, or the power needed to keep it going, is distributed across an increasing volume as the distance, the radius, increases.



### Obstruction in the way

Waves on water

If waves in water encounter the side of a boat or jetty, they will be reflected at the same angle as they met the obstruction.

#### Waves in air

If waves in air encounter a wall, they will be reflected at the same angle as they met the obstruction.



In the same way as when you bounce a ball on the wall.

### Energy loss

Waves on water

The reflected wave height is lower than the incident wave. Some of the kinetic energy is absorbed in the collision with the jetty side (and is converted into heat).

#### Waves in air

The reflected wave movement is lower than the incident wave. Some of the kinetic energy is absorbed in the collision with the wall (and is converted into heat).



The ball moves more slowly when it bounces back than when it hits the wall.

#### Sound can be absorbed

When sound waves meet a soft, porous wall (mineral wool etc.), the vibrating molecules penetrate the surface layer, and are then braked by friction against the material fibres.

The part of the energy which is thus absorbed is converted to heat in the material, and the rest is reflected back into the room. This type of damping, where the sound is braked by the soft surface layer, is referred to as porous absorption.

The sound absorption ability of different materials varies. This property is expressed as the sound absorption factor a of the material.



If nothing is absorbed, everything is reflected, then a = 0 which makes  $\alpha = 0$ :

$$i = 0 + r\alpha = \frac{0}{i} = 0$$

If nothing is reflected, everything is absorbed, then r=0 which makes  $\alpha$  = 1:

$$i = a + 0\alpha = \frac{a}{a} = 1$$

An open window can be said to have  $\alpha = 1$ , all sound from the room which arrives at the window disappears out!

In hard materials, such as concrete or marble surfaces, virtually no sound energy is absorbed, everything is reflected and the a value is near to zero. In rooms with hard surfaces, the sound bounces for a long time before it dies out. The room has a long reverberation time and we get a strong, unpleasant echo. The sound level caused by normal sound sources becomes high.

In soft materials, such as thick mineral wool boards, the opposite happens. The  $\alpha$  value is close to 1. Sometimes, excessively damped, soft rooms are unsuitable "You can't hear what you say". Avoid extremes - the reverberation time in a room should be chosen to suit the activities there.

 $\alpha$ -value



Sound, in a ventilation system, moves just as easily with or against the direction of flow.

Sound which moves through a duct system will be damped in several ways. Let us start off with bare metal duct walls.

#### Metal walls also absorb - but not much

When the metal duct walls are hit by the sound wave, they will start to vibrate at the same frequency as the sound.

The movements are normally very small, and hardly visible to the naked eye (it is often easier to feel the vibration, with your fingertips on the sheet metal).

What happens is the same as when a window vibrates when a heavy truck passes by on the street.

The duct panels and the window will then function as **membrane dampers** – boards which are made to vibrate by the incident sound energy. But this movement is not without friction, since it is braked by both the bending strength of the sheet, and (mostly) by the connection around the edges of the sheet. As previously, with the porous damper, some of the energy is converted into heat - the sound which remains has become weaker and has been damped.

Given the same free duct area, a circular, spiral seamed duct is stiffer than a rectangular one and will thus provide less damping.

As shown in the illustration on the next page, damping in un-lined ducts is relatively modest. For this reason, it is normally ignored when the noise in the installation is calculated, it is instead used as the margin of safety.

Attenuation in straight sheet metal ducts (1 mm sheet metal thickness)

# Attenuation in straight sheet etal ducts (1 mm sheet metal thickness)



A	B <b></b>	c —	D
	Circular shee	et metal ducts	
Ø75–200	200-400	400-800	800–1600
e	f <b></b>	g — · · —	• h —— · —— ·

#### Absorption is more effective

The damping becomes more effective if we put absorbent material into the duct system. The way that sound is damped was described above, part of the sound energy is absorbed by the absorption material which is hit by the sound.

If the sound waves bounce enough times against porous surfaces, the remaining sound energy, the kinetic energy which makes your eardrums vibrate, will be so low that it does not cause annoyance!



### Where should you put the absorption material in the ducts?

The answer is obvious - where the material comes into contact with the greatest number of sound waves. Noise which travels along a long, unlined, straight duct will be directed by reflection against the duct walls. Absorption material here is of less use than if it is put in a bend, a suction or pressure plenum chamber or in a straight duct just after a fan, or anywhere where we have "turbulent sound flow". The more times sound bounces against the soft sides, the more useful the material becomes.



Why the curved silencer BSLCU is so effective!



Straight silencers concentrate the absorption material

There is a complement to the description of sound waves above. When the sound waves travel along a porous surface, they will be deflected towards the duct walls. This deflection is called, "diffraction".

This, and the way that sound propagation is disturbed by turbulence, gives that straight silencers can have high attenuation.



# As we can see from the values for SLCU 50 and SLCU 100, damping varies with a few simple rules:

To attenuate low frequencies (< 500 Hz) thicker absorption material is needed. –SLCU 100 is more efficient than SLCU 50.

SLC	Ød1 Attenuation in dB for centre frequency Hz   nom mm 63 125 250 500 1k 2k 4k 8k								
Ød.	1		Attenu	ation ir	dB for	centre	freque	ncy Hz	
nom	mm	63	125	250	500	1k	2k	4k	8k
80	300	5	5	8	15	28	29	23	16
80	600	5	7	12	26	41	50	48	24
80	900	5	9	17	37	50	50	50	32
80	1200	6	11	21	49	50	50	50	40
100	300	2	2	6	14	21	25	20	11

SLC	CU 1	00										
Ød.	1	Attenuation in dB for centre frequency Hz										
nom	mm	63	125	250	500	1k	2k	4k	8k			
80	300	10	8	10	16	21	27	24	16			
80	600	12	13	19	27	37	50	46	24			
80	900	14	18	28	38	50	50	50	33			
80	1200	16	23	37	49	50	50	50	42			
100	300	5	4	11	1/	18	24	20	11			

To attenuate high frequencies (> 500 Hz), thinner absorption material is sufficient. – SLCU 50 is just as effective as SLCU 100.

SLC	CU 5	0							
Ød.	1		Attenu	ation in	dB for	centre	freque	ncy Hz	
nom	mm	63	125	250	500	1k	2k	4k	8k
80	300	5	5	8	15	28	29	23	16
80	600	5	7	12	26	41	50	48	24
80	900	5	9	17	37	50	50	50	32
80	1200	6	11	21	49	50	50	50	40
100	300	2	2	6	14	21	25	20	11

SLC	CU 10	00								
Ød.	1		Attenu	ation in	dB for	centre	freque	uency Hz		
nom	mm	63	125	250	500	1k	2k	4k	8k	
80	300	10	8	10	16	21	27	24	16	
80	600	12	13	19	27	37	50	46	24	
80	900	14	18	28	38	50	50	50	33	
80	1200	16	23	37	49	50	50	50	42	
100	300	5	4	11	14	18	24	20	11	

The longer way the sound has to pass over the absorption surface the higher the attenuation. Long silencers have higher attenuation than short ones. -SLCU with I = 600 attenuates more than SLCU with I = 300.

Øda			Attenu	ation in	dB for	centre	freque	ncy Hz	
nom	mm	63	125	250	500	1k	2k	4k	8k
80	300	5	5	8	15	28	29	23	16
80	600	5	7	12	26	41	50	48	24
80	900	5	9	17	37	50	50	50	32
80	1200	6	11	21	49	50	50	50	40
100	300	2	2	6	14	21	25	20	11

### NOTE!

The attenuation is not directly proportional to the length. The reason for this is that you get an extra attenuation at cross section area changes, and all silencers have two of them irrespective of their length.

The shorter distance between the absorbing surfaces the higher the attenuation. Silencers with small diameter attenuates more than big ones. – SLCU Ø 80 attenuates more than SLCU Ø 250.

### SLCU 50

SI CU 100

Ød₁	1		Attenua	ation ir	n dB fo	r centre	e frequ	ency H	z
nom	mm	63	125	250	500	1k	2k	4k	8k
80	300	5	5	8	15	28	29	23	16
80	600	5	7	12	26	41	50	48	24
80	900	5	9	17	37	50	50	50	32
80	1200	6	11	21	49	50	50	50	40
100	300	2	2	6	14	21	25	20	11
250	600	3	2	7	13	17	16	8	6
250	900	3	4	8	20	26	23	10	8
250	1200	4	5	9	26	35	30	12	10
315	600	0	2	6	11	14	9	4	5

**SLCBU 100** Attenuation in dB for centre frequency Hz Ød₁ Т nom mm 63 125 250 500 1k 2k 4k 8k 315 600 6 10 16 22 28 27 18 315 900 7 16 23 30 38 22 5 32 315 1200 7 9 23 30 38 47 37 25 400 600 4 5 9 13 16 15 13

# For the same reason, an extra baffle gives higher attenuation than a silencer of the same diameter, but without a baffle. – SLCBU 100 attenuates more than SLCU 100.

		••							
Øda			Attenua	ation ir	n dB foi	centre	freque	ency H	z
nom	mm	63	125	250	500	1k	2k	4k	8k
80	300	10	8	10	16	21	27	24	16
80	600	12	13	19	27	37	50	46	24
80	900	14	18	28	38	50	50	50	33
80	1200	16	23	37	49	50	50	50	42
100	300	5	4	11	14	18	24	20	11
250	900	7	7	15	18	25	23	10	9
250	1200	7	9	20	25	34	30	13	11
315	600	1	4	7	9	12	10	5	6
315	900	2	6	12	14	19	15	7	8
315	1200	2	8	16	18	26	21	9	10
400	600	1	5	5	5	7	4	4	4

#### Noise frequency influences the choice of silencer

As we see in the tables above, the damping ability varies with the frequency of sound. Before we look at the choice of silencers, it could be a good idea to describe the concept of frequency in greater detail.

A sound source influences the surrounding air, and makes it vibrate. The character of the sound depends on the variations in pressure which occur in the air.

Let us assume that the sound source is a vibrating plate - the changes in pressure, or the sound will then have the same frequency as the vibrations in the plate. The strength of the sound will depend on the amount that the plate vibrates, i.e. the amplitude of the movement. Let us start off with that:

If there is only one note, of a single frequency, the pressure will vary sinusoidally, so a pure note is referred to as a sine wave.



The characteristics of sound propagation are:

frequency (f),

which is measured in hertz, **Hz**, (s-1), (and specifies the number of times a second that a new sound wave arrives).

• wave length ( $\lambda$ , "lambda"),

which is measured in metres,  $\mathbf{m}$ , (and specifies the distance between two similar points on the curve).

#### and

speed of sound (c)

which is measured in  $\mathbf{m/s}$ , (and specifies the speed of movement of the sound wave).

These three variables have the following relationship:

 $c=f\cdot\lambda$ 

The speed of sound in air is also a function of pressure and temperature.

At normal air pressure and + 20 °C is  $c\approx 340$  m/s.

A young person with normal hearing can hear sounds at frequencies from 20-20 000 Hz, i.e. (in air) at wavelengths ranging from 17 m (at 20 Hz) to app. 17 mm (at 20 kHz).



We perceive changes in sound frequency on a logarithmic scale, i.e. it is the relative frequency and not the difference in Hz which determines how a change in note is perceived. A doubling of frequency is perceived as being the same, irrespective of whether it is a change from 100 to 200 Hz, 1000 to 2000 Hz or 10 to 20 kHz.



The logarithmic scale is usually sub-divided into octaves. i.e. in scales where the top note is twice the frequency of the bottom note. This has been customary in music for a long time.



And in engineering.



#### The concept of decibel

The stronger the sound is, the harder the particles of air will bump into each other.



Sound pressure changes in the audible area can vary within very wide limits. Some sounds are so weak that we can not hear them. The so-called **audible limit** varies with frequency and is 20 mPa at about 1000 Hz .

Other sounds are so loud that we risk hearing damage. The **pain limit**, the sound pressure which causes pain in your ears also varies with frequency, but is about 20 Pa at 1000 Hz. This means that it is a million times louder than the weakest sound we can perceive.

We also perceive changes in sound pressure on a logarithmic scale. A sound level concept using the decibel (dB) as the unit, has been created to express comparable values. The **dB** unit, which is used in many different applications, is generally defined as:  $10 \cdot \log (X/X_0)$ , where X is the unit measured, i.e. the sound pressure, and  $X_0$  is a reference level expressed in the same units. The relationship of  $X/X_0$  is thus dimensionless. The reference level from which the dB unit is specified, is given instead. This means that you generally express the level in **dB (above X\_0)**.

#### Our perception of sound

We react differently to two sounds which have the same sound pressure level and different frequencies.



Curves which describe how people normally perceive sounds of varying strength and frequency have been constructed through experiments on large numbers of volunteers. These so-called **hearing level** curves are designated by the sound pressure level for each curve at a frequency of 1 kHz. The unit used for the curves is the **phon**.

### Hearing level curves

Sound pressure level dB (over 20 mPa)



#### Example:

The sound pressure level 70 dB at 50 Hz is normally perceived as being as loud as 50 dB at 1000 Hz.

Sound levels



Several methods are used to compare the disturbance caused by two different sounds, and where the perception of the ear to noise has been modelled.



The simplest way is to compare their "weighted" sound levels. The incoming sound is filtered in an electronic filter to reduce the components, mostly the low-frequency components, where the ear is not so sensitive, and amplify the components between 1 and 4 kHz, where we are most sensitive.

Sound meters usually have three electronic filters, A-, Band C-filter. The A-filter is mostly used these days, where the result, the "weighted" **sound level**, is expressed in **dB** (A)

Attenuation dB (above 20 mPa)

0 -10 B -20 -30 -40 -50 -60 104 2 5 10<sup>2</sup> 2 5 10<sup>3</sup> 2 5 2 31 63 125 250 500 1 2 4 8 16 )

#### **Choosing silencers**

The fan is the primary sound source in a ventilation system, but intrusive noise can also be caused by an unsuitable choice of duct components and terminal units:

 $L_{W} = 40 + 10 \cdot \log \mathbf{q} + 20 \cdot \log \mathbf{p}_{\dagger} \text{ dB (above 1 pW)}$ 

q = air flow (in m<sup>3</sup>/s) through the fan

pt = total pressure rise (in Pa) in the fan

40 = "specific noise power level" which considers the efficiency of the fan at its point of operation, and the SI units for **q** and **p**<sub>t</sub>.

The noise generated in the fan must be attenuated in the duct system, at some point before the room terminal unit. Some of the attenuation is "natural", examples are given above. This attenuation is often not enough, and additional silencers can be put in the duct system - in the main channel near the fan to damp the fan noise to all the duct branches or in the branch ducts only to damp particularly sensitive rooms.

Low air speeds should be selected in the ducts, to avoid disturbing noise in the rooms.

 At a given air speed, a doubling of that speed corresponds to a 12 dB increase in noise levels.

Low air speeds also cut operating costs.

• At a given air speed, the fan power required increases as the square of the air speed.

In this example, calculation has shows that the existing attenuation in the duct system is not enough. The table shows that more attenuation is needed. What to choose?

#### Example

Duct Ø315



	63	125	250	500	1k	2k	4k	8k	
Before	Х	Х	Х	Х	Х	Х	Х	Х	dB
After	Х	Х	Х	Х	Х	Х	Х	X	dB
Difference	1	4	8	13	20	16	7	7	dB

**Lindab** has a large range of silencers with varying characteristics and dimensions. Let us see what might fit!

SLCU 50	63	125	250	500	1k	2k	4k	8k	
600	0	2	6	11	14	9	4	5	
900	1	3	7	16	22	12	6	7	1
1200	1	3	8	22	30	16	7	9	]

This is the narrowest silencer, so the longest one, 1200 mm, should be selected to meet the requirements. The deviation in the 125 Hz band, 1 dB, is small and will not be noticeable. This is one of the possible alternatives!

SLCU 100	63	125	250	500	1k	2k	4k	8k	
600	1	4	7	9	12	10	5	6	
900	2	6	12	14	19	15	7	8	•
1200	2	8	16	18	26	21	9	10	

This silencer has a thicker layer of absorbing material (100 mm instead of 50 mm) and thus has better low frequency damping, but also has a larger external diameter than SLCU 50. To meet the requirements, you should choose the longer one, 900 mm. The deviations in the 500 and 1k Hz bands, 1 dB, are small and will not be noticeable. This is an other of the possible alternatives.

SLCBU 100	63	125	250	500	1k	2k	4k	8k	
600	4	6	10	16	22	28	27	18	•
900	5	7	16	23	30	38	32	22	
1200	7	9	23	30	38	47	37	25	

This silencer has the same thickness of absorbing material as SLCU 100 (100 mm) but also has a 100 mm thick baffle which increases damping (but also the pressure drop across the silencer). You only have to choose the shortest one, 600 mm, to meet the requirements by a wide margin. The silencer manages all the octave bands by a wide margin. This is still another possible alternative.

The final choice of alternatives is determined by other considerations:

#### • SLCU 50 1200

if there is space lengthways, (but perhaps tight at the sides).

• SLCU 100 900

shorter, but needs more room at the sides.

SLCBU 100 600

If the lengthways space is limited and if the slight increase in total pressure drop is not important - e.g. in a branch duct where part of the available pressure has to be restricted anyway when the air flows are adjusted.

Decide how safe the values in the sound calculation are, and choose a silencer with the corresponding margin of safety. It is always more expensive and more difficult to add damping afterwards, if it was not installed from the beginning. If the users ever become dissatisfied with the noise, it is difficult to get them to change their views!

You can find the products under Silencers.



# Good Thinking

At Lindab, good thinking is a philosophy that guides us in everything we do. We have made it our mission to create a healthy indoor climate - and to simplify the construction of sustainable buildings. We do that by designing innovative products and solutions that are easy to use, as well as offering efficient availability and logistics. We are also working on ways to reduce our impact on our environment and climate. We do that by developing methods to produce our solutions using a minimum of energy and natural resources, and by reducing negative effects on the environment. We use steel in our products. It's one of few materials that can be recycled an infinite number of times without losing any of its properties. That means less carbon emissions in nature and less energy wasted.

We simplify construction

