Slide-on stub





Description

Slide-on stub for installation in ducts of type SR in dimension range \emptyset 560–900 where flange FL is used for joining.


After the duct has been shortened/fitted, add sealant etc between the swaged seams on the slide-on stub, after which the slide-on stub is inserted into the duct. The two swaged seams guide and retain the slide-on stub.

To finish off, the edge of the stub is swaged to both remove the sharp edge of the transition, and to fix the slide-on stub.

Please refer to the shortening instruction on page 12.

Please refer to the shortening instruction on page 12.

Dimensions



Ød	I ₁	m
nom	mm	kg
560	80	0,90
600	80	1,00
630	80	1,00
710	100	1,40
800	100	2,00
900	100	2,20

Ordering example