

Lindab flexible duct insulation **SIP**

Installation instruction


Flexible Duct Insulation

SIP

1. Open the package with the duct insulation SIP.
2. Roll out the SIP.
3. Cut the SIP to the desired length.
4. Pull out a portion of the plastic sleeve inside the SIP.




5. Attach the plastic sleeve to the duct with tape.
Note! Use protective gloves. The edge of the duct can be sharp.



Flexible Duct Insulation

SIP

6. Let a colleague hold the SIP in place.
7. From the opposite side, pull the duct through with the help of the plastic sleeve.



8. Remove the tape and plastic bag from the duct.

