



Lindab Smoke Control Damper SDJR-S

Technical manual



Table of Contents

General information	3
1. Description	3
2. Design	4
3. Dimensions, weights	12
4. Placement and Assembly	16
5. Suspension system	17
Technical data	18
6. Pressure loss	18
10. Noise data	19
Material, finish	20
8. Material	20
Inspection, testing	20
9. Inspection, testing	20
Transportation and storage	21
10. Logistic terms	21
Assembly, attendance, maintenance and revision	21
11. Assembly	21
12. Entry into service and revisions	22
13. Spare parts	22
Product data	22
14. Product label	22
Ordering information	23
15. Ordering example	23



SDJR-S

General information

1. Description

1.1. Smoke control dampers - single are shutters in smoke exhaust piping systems. Dampers are designed to remove heat and combustion products (e.g. smoke) from single fire compartment. In the event of fire the Smoke and Fire ventilation system opens the damper in the affected section which removes combustion products and heat from this section.

The damper blade is operated by an actuating mechanism.

The dampers can be installed in various duct sizes with respect to the field of direct applications according with EN1366-9.

The field of direct applications based on tests results is acceptable according to EN1363-1, part A.1 and A.2, EN1366-2, part 13 and EN1366-10, part 9.

Smoke control dampers - single are classified as

 E_{600} 120 (v_e - i \leftrightarrow o) S1500 C_{mod} MA Single

The duct can be ended by KMM (TPM 002/96) grilles.

1.2. Damper characteristics

- CE certified acc. to EN12101-8
- Tested in accordance with EN1366-10
- Classified acc. to EN13501- 4+A1
- External Casing leakage min. class B, Internal leakage min. class 3 acc. to EN1751
- Cycling test in class Cmod acc. to EN12101-8
- ES Certificate No. 1391-CPR-2020/0187
- Declaration of Perfomance SDJR-S DoP
- Hygienic assessment of fire dampers Report No. 1.6/pos/19/19c

1.3. Working conditions

- Dampers are designed for smoke exhaust piping systems with underpressure max. 1500 Pa or overpressure max. 500 Pa.
- Dampers are designed for maximum air velocity 12 m/s.
- Dampers are installed with the horizontal or vertical axis of the blades.
- Dampers are intended for installation on air ducts and in/onto the walls where in the case of wall installation, this wall with damper does not have fire resistance and therefore does not separate two fire compartments.
- Dampers are suitable for systems without abrasive, chemical and adhesive particles.
- Dampers are designed for macroclimatic areas with mild climate according to EN 60 721-3-3. Temperature in the place of installation is permitted to range from -20°C to +50°C.



SDJR-S

2. Design

2.1. Design with actuating mechanism


Design .44 and .54

Belimo actuators are used for dampers, series BEN, BEE, BE for 230V AC resp. 24V AC/DC.

After connection to the power supply voltage, the actuator moves the damper blade to the "OPEN" position or "CLOSED" (according to the corresponding connection, see wiring diagram). If the power supply is interrupted, the actuator stops at the current position. The signalling of the "OPEN" and "CLOSED" damper blade positions is ensured by two built-in fixed "potential-free" end- limit switches.

The actuator for operating the damper blade is mounted in an insulated cover/box. It is accessible after removing the cover lid. The electrical connection of the actuator is made with a non- flammable cable (or a cable located in the adjoining cable duct), which passes through an opening made in the wall of the insulated cover/boxwhen installing the damper or when connecting the actuator power cable. The cable entry must meet a minimum fire resistance of 30 minutes.

Fig.1 Damper SDJR-S - actuating mechanism in the cover





Tab. 2.1.1. Actuator BELIMO BEN 24(-ST), BEN 24-SR, BEN 230

Actuator BELIMO - 15Nm	BEN 24(-ST)	BEN 24-SR	BEN 230			
Power voltage	AC/DC 24V 50/60Hz	AC/DC 24V 50/60Hz	AC 230V 50/60Hz			
Power consumption - in operation - in the end position	3W 0,1W	3W 0,3W	4W 0,4W			
Dimensioning	6VA (Imax8,2 A @ 5ms)	6,5 VA (Imax8.2 A @ 5ms)	7VA (Imax4 A @ 5ms)			
Protection class	III	III	II			
Degree of protection		IP 54				
Adjustment time for 95°		< 30s				
Ambient temperature Storage temperature	-30°C +55°C -40°C +80°C					
Connection - drive - auxiliary switch	Cable 1m, 3x0,75mm ² Cable 1m, 6x0,75mm ² (BEN 24-ST) with plug connectors	Cable 1m, 4x0,75mm ² Cable 1m, 6x0,75mm ²	Cable 1m, 3x0,75mm ² Cable 1m, 6x0,75mm ²			

Fig. 2 Actuator BELIMO BEN 24(-ST)



Fig. 3 Actuator BELIMO BEN 24-SR



Fig. 4 Actuator BELIMO BEN 230



Tab. 2.1.2. Actuator BELIMO BEE 24(-ST), BEE 24-SR, BEE 230

Actuator BELIMO - 25Nm	BEE 24(-ST)	BEE 24-SR	BEE 230		
Power voltage	AC/DC 24V 50/60Hz	AC/DC 24V 50/60Hz	AC 230V 50/60Hz		
Power consumption - in operation - in the end position	ration 2,5W 3W				
Dimensioning	5VA (Imax8,2 A @ 5ms)	5,5VA (Imax8.2 A @ 5ms)	6VA (Imax4 A @ 5ms)		
Protection class	III	III	II		
Degree of protection		IP 54			
Adjustment time for 95°		< 60s			
Ambient temperature Storage temperature		-30°C +55°C -40°C +80°C			
Connection - drive - auxiliary switch	Cable 1m, 3x0,75mm ² Cable 1m, 6x0,75mm ² (BEE 24-ST) with plug connectors	Cable 1m, 4x0,75mm ² Cable 1m, 6x0,75mm ²	Cable 1m, 3x0,75mm ² Cable 1m, 6x0,75mm ²		

Fig. 5 Actuator BELIMO BEE 24(-ST)





SDJR-S

Actuator BELIMO BEE 24-SR Fig. 6




Fig. 7 **Actuator BELIMO BEE 230**



Tab. 2.1.3. Actuator BELIMO BE 24-12(-ST), BE 230-12

Actuator BELIMO - 40Nm	BE 24-12(-ST)	BE 230-12				
Power voltage	AC/DC 24V 50/60Hz	AC 230V 50/60Hz				
Power consumption - in operation - in the end position	12W 0,5W	8W 0,5W				
Dimensioning	18VA (Imax8,2 A @ 5 ms)	15VA (Imax7,9 A @ 5ms)				
Protection class	III	II				
Degree of protection		IP 54				
Adjustment time for 95°		< 60s				
Ambient temperature Storage temperature	-30°C +50°C -40°C +80°C					
Connection - drive - auxiliary switch	Cable 1m, 3x0,75mm ² Cable 1m, 6x0,75mm ² (BE 24-ST) with plug connectors					

Fig. 8 Actuator BELIMO BE 24-12(-ST)



Fig. 9 Actuator BELIMO BE 230-12





SDJR-S

2.2. Design with the communication and power supply unit

Design .66

Design with communication and power supply device BKNE 230-24 and with actuator BEN (BEE, BE)-ST pro 24V.

The BKNE 230-24 serves on the one hand as a decentralized network device for powering the actuator and on the other hand transmits the signal of the communication and control device BKSE 24-6.

It simplifies electrical installation and connection of dampers. In the meantime, it facilitates "on-site inspection" and allows central control and inspection of dampers using a simple 2-wire line.

The BKNE 230-24 transmits the "OPEN" / "CLOSED" damper position (switches in the actuator) and fault messages to the BKSE 24-6. It also receives commands from the control device and controls the adjustment of the actuator to the desired position. The last control command will be retained even after a temporary network failure..


The BKNE 230-24 controls the switching position of the actuator, its adjustment time and the data exchange with the BKSE 24-6. In addition, it controls the actuator current (actuator connection) and the power supply.

To simplify the connection, the actuator is equipped with plug connectors that plug directly into the BKNE 230-24.

The actuator, communication and power supply device BKNE 230-24 are mounted in an insulated cover, they are accessible after removing the cover. The electrical connection of the actuator and the BKNE 230-24 communication and power supply device is made with a non-flammable cable (or a cable located in an adjoining cable duct), the two-wire BKNE 230-24 cable should be connected to terminals 6 and 7. It is also recommended to use cable, which is used for fire signalling network. The cables pass through an opening made in the wall of the insulated cover when installing the damper or when connecting the actuator power cable. The cable entry must meet a minimum fire resistance of 30 minutes.

For more information on actuators and devices, see the Belimo catalogue.

Fig. 10 Damper SDJR-S - actuating machanism and BKNE in the cover




SDJR-S

2.3. Communication and supply device

Tab. 2.3.1. Communication and power supply device BKNE 230-24

Communication and power supply device	BKNE 230-24
Power voltage	AC 230V 50/60Hz
Power consumption	10W (including actuator)
Dimensioning	19VA (including actuator)
Protection class	II
Ambient operation temperature Storage temperature	-30°C +50°C -40°C +80°C
Connecting - network - drive - terminal blocks	cable 1m without plug 6-pin plug, 3-pin plug screw terminals for 2x1.5mm² conductor

Fig. 11 Communication and power supply device BKNE 230-24





2.4. Communication and control device

BKSE 24-6 indicates operating condition and faults of flue dampers. These conditions can be signalled or transmitted to the higher-level control system via the auxiliary built-in contacts. Signals from individual BKNE 230-24 are evaluated separately. All BKNE 230-24 are controlled simultaneously. A maximum of 6 BKNE 230-24 can be connected to the BKSE 24-6.


Damper control is ensured with a simple 2-wire line. The damper's correct function is indicated by two LEDs. The operating status of the entire control system and any errors are indicated by these LEDs and the corresponding error LED.

Mounting and connection of BKSE 24-6 can be done on a 35mm DIN rail. It's connected using two 9-pin terminal blocks (plug connectors).

Tab. 2.4.1. Communication and control devices BKSE 24-6

Communication and control devices	BKSE 24-6				
Power voltage	AC 24V 50/60Hz				
Power consumption	3,5W (operating position)				
Dimensioning	5,5VA 18 A (Imax6.4 A @ 2.5ms)				
Protection class	III (low voltage)				
Degree of protection	IP 20				
Ambient operation temperature	0+50°C				
Connection	screw terminals for 2x1.5mm ² conductor				

Fig. 12 Communication and control devices BKSE 24-6




SDJR-S

3. Dimensions, weights

3.1. Dimensions

Fig. 13 Damper SDJR-S



*standard height of the flange

Position:

- 1. Damper body
- 2. Damper plate
- 3. Actuating mechanism cover

Actuating mechanism	V [mm]	D [mm]
BEN / BEE	176,5	300
BE	186,5	380
BEN / BEE + BKNE	236,5	300
BE + BKNE	251,5	380



SDJR-S

3.2. Weights and effective area cross section

Tab. 3.2.1. Weights and effective area cross section

Size AxB	Number of blades	Weight [kg]	Sef [m²]	Actuating Mechanism	Size AxB	Number of blades	Weight [kg]	Sef [m²]	Actuating Mechanism
200x200	1	14.3	0.0227	BEN	350x200	1	16.8	0.0440	BEN
x250	2	16.4	0.0270	BEN	x250	2	19.3	0.0524	BEN
x300	2	17.3	0.0350	BEN	x300	2	20.4	0.0679	BEN
x350	2	18.3	0.0430	BEN	x350	2	21.6	0.0834	BEN
x400	2	19.2	0.0510	BEN	x400	2	22.7	0.0989	BEN
x450	3	21.2	0.0554	BEN	x450	3	25.1	0.1073	BEN
x500	3	22.2	0.0634	BEN	x500	3	26.2	0.1228	BEN
x600	3	24.1	0.0794	BEN	x600	3	28.5	0.1538	BEN
x700	4	27.0	0.0917	BEN	x700	4	32.0	0.1776	BEN
x800	4	28.9	0.1077	BEN	x800	4	34.3	0.2086	BEN
x900	5	34.5	0.1200	BEE	x900	5	40.5	0.2325	BEE
x1000	5	36.4	0.1360	BEE	x1000	5	42.7	0.2635	BEE
x1100	6	39.3	0.1483	BEE	x1100	6	46.3	0.2874	BEE
x1200	6	41.2	0.1643	BEE	x1200	6	48.5	0.3184	BEE
250x200	1	15.1	0.0298	BEN	400x200	1	17.6	0.0511	BEN
x250	2	17.4	0.0355	BEN	x250	2	20.3	0.0608	BEN
x300	2	18.4	0.0460	BEN	x300	2	21.5	0.0788	BEN
x350	2	19.4	0.0565	BEN	x350	2	22.6	0.0968	BEN
x400	2	20.4	0.0670	BEN	x400	2	23.8	0.1148	BEN
x450	3	22.5	0.0727	BEN	x450	3	26.4	0.1246	BEN
x500	3	23.5	0.0832	BEN	x500	3	27.6	0.1426	BEN
x600	3	25.5	0.1042	BEN	x600	3	30.0	0.1786	BEN
x700	4	28.7	0.1203	BEN	x700	4	33.7	0.2063	BEN
x800	4	30.7	0.1413	BEN	x800	4	36.1	0.2423	BEN
x900	5	36.5	0.1575	BEE	x900	5	42.5	0.2700	BEE
x1000	5	38.5	0.1785	BEE	x1000	5	44.8	0.3060	BEE
x1100	6	41.6	0.1947	BEE	x1100	6	48.6	0.3337	BEE
x1200	6	43.6	0.2157	BEE	x1200	6	51.0	0.3697	BEE
300x200	1	15.9	0.0369	BEN	450x200	1	18.4	0.0582	BEN
x250	2	18.3	0.0439	BEN	x250	2	21.3	0.0693	BEN
x300	2	19.4	0.0569	BEN	x300	2	22.5	0.0898	BEN
x350	2	20.5	0.0699	BEN	x350	2	23.7	0.1103	BEN
x400	2	21.5	0.0829	BEN	x400	2	25.0	0.1308	BEN
x450	3	23.8	0.0900	BEN	x450	3	27.7	0.1419	BEN
x500	3	24.9	0.1030	BEN	x500	3	28.9	0.1624	BEN
x600	3	27.0	0.1290	BEN	x600	3	31.4	0.2034	BEN
x700	4	30.3	0.1490	BEN	x700	4	38.0	0.2349	BEE
x800	4	32.5	0.1750	BEN	x800	4	40.5	0.2759	BEE
x900	5	38.5	0.1950	BEE	x900	5	44.5	0.3075	BEE
x1000	5	40.6	0.2210	BEE	x1000	5	47.0	0.3485	BEE
x1100	6	43.9	0.2410	BEE	x1100	6	50.9	0.3801	BEE
x1200	6	46.1	0.2670	BEE	x1200	6	53.4	0.4211	BEE

* table continues on next page



Tab. 3.2.1. Weights and effective area cross section

Size AxB	Number of blades	Weight [kg]	Sef [m²]	Actuating Mechanism	Size AxB	Number of blades	Weight [kg]	Sef [m²]	Actuating Mechanism
500x200	1	19.2	0.0653	BEN	800x200	1	24.2	0.1079	BEN
x250	2	22.2	0.0777	BEN	x250	2	28.1	0.1284	BEN
x300	2	23.5	0.1007	BEN	x300	2	29.7	0.1664	BEN
x350	2	24.8	0.1237	BEN	x350	2	31.4	0.2044	BEN
x400	2	26.1	0.1467	BEN	x400	2	33.0	0.2424	BEN
x450	3	29.0	0.1592	BEN	x450	3	36.8	0.2630	BEN
x500	3	30.3	0.1822	BEN	x500	3	38.4	0.3010	BEN
x600	3	32.9	0.2282	BEN	x600	3	41.7	0.3770	BEN
x700	4	39.7	0.2636	BEE	x700	4	49.8	0.4355	BEE
x800	4	42.3	0.3096	BEE	x800	4	53.1	0.5115	BEE
x900	5	46.5	0.3450	BEE	x900	5	58.5	0.5700	BE
x1000	5	49.1	0.3910	BEE	x1000	5	61.8	0.6460	BE
x1100	6	53.2	0.4264	BEE	x1100	6	67.2	0.7045	BE
x1200	6	55.8	0.4724	BE	x1200	6	70.5	0.7805	BE
600x200	1	20.9	0.0795	BEN	900x200	1	25.8	0.1221	BEN
x250	2	24.2	0.0946	BEN	x250	2	30.0	0.1453	BEN
x300	2	25.6	0.1226	BEN	x300	2	31.8	0.1883	BEN
x350	2	27.0	0.1506	BEN	x350	2	33.5	0.2313	BEN
x400	2	28.4	0.1786	BEN	x400	2	35.3	0.2743	BEN
x450	3	31.6	0.1938	BEN	x450	3	39.4	0.2976	BEN
x500	3	33.0	0.2218	BEN	x500	3	41.1	0.3406	BEN
x600	3	35.8	0.2778	BEN	x600	3	47.3	0.4266	BEE
x700	4	43.1	0.3209	BEE	x700	4	53.1	0.4928	BEE
x800	4	45.9	0.3769	BEE	x800	4	56.7	0.5788	BE
x900	5	50.5	0.4200	BEE	x900	5	62.5	0.6450	BE
x1000	5	53.3	0.4760	BEE	x1000	5	66.0	0.7310	BE
x1100	6	57.9	0.5191	BE	x1100	6	71.8	0.7972	BE
x1200	6	60.7	0.5751	BE	x1200	6	75.4	0.8832	BE
700x200	1	22.5	0.0937	BEN	1000x200	1	27.5	0.1363	BEN
x250	2	26.1	0.1115	BEN	x250	2	32.0	0.1622	BEN
x300	2	27.7	0.1445	BEN	x300	2	33.9	0.2102	BEN
x350	2	29.2	0.1775	BEN	x350	2	35.7	0.2582	BEN
x400	2	30.7	0.2105	BEN	x400	2	37.6	0.3062	BEN
x450	3	34.2	0.2284	BEN	x450	3	42.0	0.3322	BEN
x500	3	35.7	0.2614	BEN	x500	3	43.9	0.3802	BEN
x600	3	38.8	0.3274	BEN	x600	3	50.3	0.4762	BEE
x700	4	46.4	0.3782	BEE	x700	4	56.5	0.5501	BE
x800	4	49.5	0.4442	BEE	x800	4	60.3	0.6461	BE
x900	5	54.5	0.4950	BEE	x900	5	66.5	0.7200	BE
x1000	5	57.5	0.5610	BE	x1000	5	70.2	0.8160	BE
x1100	6	62.5	0.6118	BE	x1100	6	76.5	0.8899	BE
x1200	6	65.6	0.6778	BE	x1200	6	80.2	0.9859	BE ntinues on next pag

Lindab®

SDJR-S

Tab. 3.2.1. Weights and effective area cross section

Size AxB	Number of blades	Weight [kg]	Sef [m²]	Actuating Mechanism	Size AxB	Number of blades	Weight [kg]	Sef [m²]	Actuating Mechanism
1100x200	1	29.1	0.1505	BEN	1200x200	1	30.8	0.1647	BEN
x250	2	34.0	0.1791	BEN	x250	2	35.9	0.1960	BEN
x300	2	35.9	0.2321	BEN	x300	2	38.0	0.2540	BEN
x350	2	37.9	0.2851	BEN	x350	2	40.1	0.3120	BEN
x400	2	39.9	0.3381	BEN	x400	2	42.2	0.3700	BEN
x450	3	47.2	0.3668	BEE	x450	3	49.8	0.4014	BEE
x500	3	49.2	0.4198	BEE	x500	3	51.9	0.4594	BEE
x600	3	53.2	0.5258	BEE	x600	3	56.1	0.5754	BE
x700	4	59.9	0.6074	BE	x700	4	63.2	0.6647	BE
x800	4	63.8	0.7134	BE	x800	4	67.4	0.7807	BE
x900	5	70.5	0.7950	BE	x900	5	74.5	0.8700	BE
x1000	5	74.5	0.9010	BE	x1000	5	78.7	0.9860	BE
x1100	6	81.1	0.9826	BE	x1100	6	85.8	1.0753	BE
x1200	6	85.1	1.0886	BE	x1200	6	90.0	1.1913	BE

If is used the communication and supply device BKNE230-24, the weight is higher by 0,68 kg.

Example, how to calculate effective area and size of SDJR-S damper [AxB], when knowing air volume in [m³/s] or [m³/h] on damper. Maximum allowed air velocity on SDJR-S is 12 [m/s].

Formula:

Sef = Q / v

Q ... air volume [m3/s]

Sef ... effective free area of damper $[m^2]$ v ... air velocity on damper [m/s]

Example:

Air volume needed is 26000 m³/h

26000 / 3600 = 7,222 m³/s

 $7,222 / 12 = 0,602 \text{ m}^2 \text{ is min. effective free area [Sef]}$

Find the value Sef in the table 3.2.1. The effective are has to be the same or bigger. There will be more options of damper, sizes AxB.



SDJR-S

4. Placement and Assembly


4.1. Smoke control dampers single are designed to remove heat and combustion products (e.g. smoke) from single fire compartment according EN1366-9.

Smoke control dampers single are designed for installation with horizontal or vertical axis of the blades. Backtoback smoke exhaust duct has to be hung or supported so as all load transfer from the backtoback smoke exhaust duct to the damper is absolutely excluded. To provide needed access space to the control device, all other objects must be situated at least 350 mm from the control parts of the damper.

4.2. During installation the damper blade must be in position CLOSED. The damper body should not be deformed in the course of installation. Once the damper built in, its blade should not grind on the damper body during opening or closing.

4.3. Installation example


Fig. 14 Installation example



5. Suspension system

7.1. Mounting to the ceiling wall

Fig. 15 Mounting to the ceiling wall



Position:

- 1. Threaded rod M8 M20
- 2. Nut
- 3. Washer
- 4. Coupling Nut
- 5. Anchor
- 6. Hinge plate min. thickness 10 mm
- 7. Concrete screw tested for fire resistance R30-R90, max. Tension up to 0.75 KN (length 35 mm)


Size	A [2]	Weight G [kg]				
Size	A _s [mm²]	for 1 piece	for 1 pair			
M8	36,6	22	44			
M10	58	35	70			
M12	84,3	52	104			
M14	115	70	140			
M16	157	96	192			
M18	192	117	234			
M20	245	150	300			

SDJR-S

Technical data

6. Pressure loss

Diagram 6.1. Pressure drops of the damper was determined for air density 1,2 kg/m³





SDJR-S

10. Noise data

7.1. Sound power level corrected with filter A

Tab. 7.1.1. Sound power level Lw in dB(A) for B=250/300/450mm, damper fully open

	f (Hz)	63	125	250	500	1000	2000	4000	8000	Total
	2	16	24	29	29	28	26	23	9	35
	3	25	33	38	38	37	35	32	18	44
	4	32	40	45	45	44	42	39	25	51
	5	38	46	51	51	50	48	45	31	57
(s/u	6	42	50	55	55	54	52	49	35	61
w (m/s)	7	46	54	59	59	58	56	53	39	65
	8	49	57	62	62	61	59	56	42	68
	9	50	58	63	63	62	60	57	43	69
	10	53	61	66	66	65	63	60	46	72
	11	55	63	68	68	67	65	62	48	74
	12	57	65	70	70	69	67	64	50	76

w - air velocity in the free cross section (AxB) - i.e. before blades

Tab. 7.1.2. Sound power level Lw in dB(A) for B=350/500/700/900/1100mm, damper fully open

	f (Hz)	63	125	250	500	1000	2000	4000	8000	Total
	2	15	23	28	28	27	25	22	8	34
	3	24	32	37	37	36	34	31	17	43
	4	31	39	44	44	43	41	38	24	50
	5	36	44	49	49	48	46	43	29	55
w (m/s)	6	41	49	54	54	53	51	48	34	60
u) w	7	45	53	58	58	57	55	52	38	64
	8	48	56	61	61	60	58	55	41	67
	9	49	57	62	62	61	59	56	42	68
	10	51	59	64	64	63	61	58	44	70
	11	53	61	66	66	65	63	60	46	72
	12	55	63	68	68	67	65	62	48	74

f - frequency of octave band

SDJR-S

Tab. 7.1.3. Sound power level Lw in dB(A) for B=200/400/600/800/1000/1200mm, damper fully open

	f (Hz)	63	125	250	500	1000	2000	4000	8000	Total
(s/ш) м	2	13	21	26	26	25	23	20	6	32
	3	21	29	34	34	33	31	28	14	40
	4	28	36	41	41	40	38	35	21	47
	5	34	42	47	47	46	44	41	27	53
	6	38	46	51	51	50	48	45	31	57
	7	42	50	55	55	54	52	49	35	61
	8	45	53	58	58	57	55	52	38	64
	9	47	55	60	60	59	57	54	40	66
	10	48	56	61	61	60	58	55	41	67
	11	50	58	63	63	62	60	57	43	69
	12	52	60	65	65	64	62	59	45	71

w - air velocity in the free cross section (AxB) - i.e. before blades

Material, finish

8. Material

- 8.1. Damper casing and damper blade are made of galvanized plate without any other surface finish.
- 8.2. Fasteners are galvanized.
- 8.3. The actuator cover is made of fire-resistant material (fire protection board)

Inspection, testing

9. Inspection, testing

9.1. 9.1. The appliance is constructed and preset by the manufacturer, its operation is dependent on proper installation and adjustment.



f - frequency of octave band

SDJR-S

Transportation and storage

10. Logistic terms

- **10.1.** Dampers are transported by boxfreight vehicles without direct weather impact, there must not occur any shocks and ambient temperature must not exceed +40°C. Dampers must be protected against mechanic damages when transported and manipulated. During transportation, the damper blade must be in the "CLOSED" position.
- **10.2.** Dampers are stored indoor in environment without any aggressive vapours, gases or dust. Indoor temperature must be in the range from -5°C to +40°C and maximum relative humidity 80%. Dampers must be protected against mechanic damages when transported and manipulated.

Assembly, attendance, maintenance and revision


11. Assembly

- **11.1.** Assembly, maintenance and damper function check can be done only by qualified and trained person, i.e. "AUTHOR-IZED PERSON" according to the manufacturer documentation. All works done on the fire dampers must be done according international and local norms and laws.
- 11.2. All effective safety standards and directives must be observed during damper assembly.
- **11.3.** To ensure reliable smoke exhaust damper function it is necessary to avoid blocking the closing mechanism and contact surfaces with collected dust, fibre and sticky materials and solvents.

11.4. Manual operation

Without power supply, the damper can be operated manually and fixed in any required position.

Fig. 16 Connecting hole





12. Entry into service and revisions

- **12.1.** Before entering the dampers into operation after assembly and after sequential revisions, checks and functionality tests of all designs including operation of the electrical components must be successfully provided and finished. After entering into operation, these revisions must be done according to requirement set by national regulations.
- **12.1.1.** In case that dampers are found unable to serve for their function for any cause, it must be clearly marked. The operator is obliged to ensure that the damper is put into condition in which it is ready for function and meanwhile he is obliged to provide the fire protection by another appropriate way.
- **12.1.2.** Results of regular checks, imperfections found and all-important facts connected with the damper function must be recorded in the "FIRE BOOK" and immediately reported to the operator.
- **12.2.** Before entering the dampers into operation after their assembly and by sequential checks, the following checks must be carried out for all designs.
- **12.2.1.** Visual inspection of proper damper integration, inside damper area, damper blade, contact surfaces and silicon sealing.
- **12.2.2.** Check of damper blade displacement can be realize after actuating mechanism supply connection or signal connection from higher level control systems. Blade displacement from position "OPEN" to position "CLOSED" and return displacement is checked.

13. Spare parts


13.1. Spare parts are supplied only on basis of an order.

Product data

14. Product label

14.1. Product label is placed on the damper casing

Fig. 17 Product label (Nameplate)





SDJR-S

Ordering information

15. Ordering example

	SDJR-S	180	180	230V	Yes	30mm
Product						
Width						
Height						
Actuator						
Insulated blade						
Flanges/grilles						

Example: SDJR-S-200-200-230V-Insulated-30mm





Good Thinking

At Lindab, good thinking is a philosophy that guides us in everything we do. We have made it our mission to create a healthy indoor climate - and to simplify the construction of sustainable buildings. We do that by designing innovative products and solutions that are easy to use, as well as offering efficient availability and logistics. We are also working on ways to reduce our impact on our environment and climate. We do that by developing methods to produce our solutions using a minimum of energy and natural resources, and by reducing negative effects on the environment. We use steel in our products. It's one of few materials that can be recycled an infinite number of times without losing any of its properties. That means less carbon emissions in nature and less energy wasted.

We simplify construction

