


# Lindab **Access door IPF**

Mounting instruction

# Access door

IPF



- 1 Access door
- 2 Hand knobs
- 3 Inner plate

1. Cut a hole in the duct wall for the access door, 15 mm narrower and 15 mm shorter than the access door being used (for example: 115 × 215mm access door size = hole size 100 × 200mm).
2. Unscrew the hand knobs until the end of the hand knob screws (Fig. 1).
3. Slip inner plate through duct opening at an angle (Fig. 2).
4. Align the access door into position.
5. Tighten the hand knobs (Fig. 3).




Fig. 1




Fig. 2




Fig. 3

Hint! A self adhesive template is provided with the access door to assist in cutting the correct sized hole in the duct wall.



Most of us spend the majority of our time indoors. Indoor climate is crucial to how we feel, how productive we are and if we stay healthy.

We at Lindab have therefore made it our most important objective to contribute to an indoor climate that improves people's lives. We do this by developing energy-efficient ventilation solutions and durable building products. We also aim to contribute to a better climate for our planet by working in a way that is sustainable for both people and the environment.

[Lindab | For a better climate](#)