

Cross Reference List of Modbus Slave

Tool Modbus slave
 Controller FDSMaster, LindabFDS

Modbus Device Address: 15
 TCP/IP Enabled: Yes
 Serial Port 2, bit rate: 9600, format: No parity + 2 stop bits

Object Type	Addr	Scale	EXOL Variable	Description
Discrete input	701		Alarmhandler_FireAlarm1	Fire Alarm Damper/detector 1
Input register	701	1	Alarmhandler_FireAlarm1_Status	Fire Alarm Damper/detector 1 0 = Not used 1 = Normal 2 = Blocked 3 = Acknowledged 4 = Not used 5 = Returned 6 = Not used 7 = Alarmed
Discrete input	710		Alarmhandler_FireAlarm10	Fire Alarm Damper/detector 10
Input register	710	1	Alarmhandler_FireAlarm10_Status	Fire Alarm Damper/detector 10
Discrete input	711		Alarmhandler_FireAlarm11	Fire Alarm Damper/detector 11
Input register	711	1	Alarmhandler_FireAlarm11_Status	Fire Alarm Damper/detector 11
Discrete input	712		Alarmhandler_FireAlarm12	Fire Alarm Damper/detector 12
Input register	712	1	Alarmhandler_FireAlarm12_Status	Fire Alarm Damper/detector 12
Discrete input	713		Alarmhandler_FireAlarm13	Fire Alarm Damper/detector 13
Input register	713	1	Alarmhandler_FireAlarm13_Status	Fire Alarm Damper/detector 13
Discrete input	714		Alarmhandler_FireAlarm14	Fire Alarm Damper/detector 14
Input register	714	1	Alarmhandler_FireAlarm14_Status	Fire Alarm Damper/detector 14
Discrete input	715		Alarmhandler_FireAlarm15	Fire Alarm Damper/detector 15
Input register	715	1	Alarmhandler_FireAlarm15_Status	Fire Alarm Damper/detector 15
Discrete input	716		Alarmhandler_FireAlarm16	Fire Alarm Damper/detector 16
Input register	716	1	Alarmhandler_FireAlarm16_Status	Fire Alarm Damper/detector 16
Discrete input	717		Alarmhandler_FireAlarm17	Fire Alarm Damper/detector 17
Input register	717	1	Alarmhandler_FireAlarm17_Status	Fire Alarm Damper/detector 17
Discrete input	718		Alarmhandler_FireAlarm18	Fire Alarm Damper/detector 18
Input register	718	1	Alarmhandler_FireAlarm18_Status	Fire Alarm Damper/detector 18
Discrete input	719		Alarmhandler_FireAlarm19	Fire Alarm Damper/detector 19
Input register	719	1	Alarmhandler_FireAlarm19_Status	Fire Alarm Damper/detector 19

Discrete input	702		Alarmhandler_FireAlarm2	Fire Alarm Damper/detector 2
Input register	702	1	Alarmhandler_FireAlarm2_Status	Fire Alarm Damper/detector 2
Discrete input	720		Alarmhandler_FireAlarm20	Fire Alarm Damper/detector 20
Input register	720	1	Alarmhandler_FireAlarm20_Status	Fire Alarm Damper/detector 20
Discrete input	721		Alarmhandler_FireAlarm21	Fire Alarm Damper/detector 21
Input register	721	1	Alarmhandler_FireAlarm21_Status	Fire Alarm Damper/detector 21
Discrete input	722		Alarmhandler_FireAlarm22	Fire Alarm Damper/detector 22
Input register	722	1	Alarmhandler_FireAlarm22_Status	Fire Alarm Damper/detector 22
Discrete input	723		Alarmhandler_FireAlarm23	Fire Alarm Damper/detector 23
Input register	723	1	Alarmhandler_FireAlarm23_Status	Fire Alarm Damper/detector 23
Discrete input	724		Alarmhandler_FireAlarm24	Fire Alarm Damper/detector 24
Input register	724	1	Alarmhandler_FireAlarm24_Status	Fire Alarm Damper/detector 24
Discrete input	725		Alarmhandler_FireAlarm25	Fire Alarm Damper/detector 25
Input register	725	1	Alarmhandler_FireAlarm25_Status	Fire Alarm Damper/detector 25
Discrete input	726		Alarmhandler_FireAlarm26	Fire Alarm Damper/detector 26
Input register	726	1	Alarmhandler_FireAlarm26_Status	Fire Alarm Damper/detector 26
Discrete input	727		Alarmhandler_FireAlarm27	Fire Alarm Damper/detector 27
Input register	727	1	Alarmhandler_FireAlarm27_Status	Fire Alarm Damper/detector 27
Discrete input	728		Alarmhandler_FireAlarm28	Fire Alarm Damper/detector 28
Input register	728	1	Alarmhandler_FireAlarm28_Status	Fire Alarm Damper/detector 28
Discrete input	729		Alarmhandler_FireAlarm29	Fire Alarm Damper/detector 29
Input register	729	1	Alarmhandler_FireAlarm29_Status	Fire Alarm Damper/detector 29
Discrete input	703		Alarmhandler_FireAlarm3	Fire Alarm Damper/detector 3
Input register	703	1	Alarmhandler_FireAlarm3_Status	Fire Alarm Damper/detector 3
Discrete input	730		Alarmhandler_FireAlarm30	Fire Alarm Damper/detector 30
Input register	730	1	Alarmhandler_FireAlarm30_Status	Fire Alarm Damper/detector 30
Discrete input	731		Alarmhandler_FireAlarm31	Fire Alarm Damper/detector 31
Input register	731	1	Alarmhandler_FireAlarm31_Status	Fire Alarm Damper/detector 31
Discrete input	732		Alarmhandler_FireAlarm32	Fire Alarm Damper/detector 32
Input register	732	1	Alarmhandler_FireAlarm32_Status	Fire Alarm Damper/detector 32
Discrete input	733		Alarmhandler_FireAlarm33	Fire Alarm Damper/detector 33
Input register	733	1	Alarmhandler_FireAlarm33_Status	Fire Alarm Damper/detector 33
Discrete input	734		Alarmhandler_FireAlarm34	Fire Alarm Damper/detector 34
Input register	734	1	Alarmhandler_FireAlarm34_Status	Fire Alarm Damper/detector 34
Discrete input	735		Alarmhandler_FireAlarm35	Fire Alarm Damper/detector 35
Input register	735	1	Alarmhandler_FireAlarm35_Status	Fire Alarm Damper/detector 35
Discrete input	736		Alarmhandler_FireAlarm36	Fire Alarm Damper/detector 36
Input register	736	1	Alarmhandler_FireAlarm36_Status	Fire Alarm Damper/detector 36
Discrete input	737		Alarmhandler_FireAlarm37	Fire Alarm Damper/detector 37
Input register	737	1	Alarmhandler_FireAlarm37_Status	Fire Alarm Damper/detector 37
Discrete input	738		Alarmhandler_FireAlarm38	Fire Alarm Damper/detector 38
Input register	738	1	Alarmhandler_FireAlarm38_Status	Fire Alarm Damper/detector 38
Discrete input	739		Alarmhandler_FireAlarm39	Fire Alarm Damper/detector 39
Input register	739	1	Alarmhandler_FireAlarm39_Status	Fire Alarm Damper/detector 39
Discrete input	704		Alarmhandler_FireAlarm4	Fire Alarm Damper/detector 4

Input register	704	1	Alarmhandler_FireAlarm4_Status	Fire Alarm Damper/detector 4
Discrete input	740		Alarmhandler_FireAlarm40	Fire Alarm Damper/detector 40
Input register	740	1	Alarmhandler_FireAlarm40_Status	Fire Alarm Damper/detector 40
Discrete input	741		Alarmhandler_FireAlarm41	Fire Alarm Damper/detector 41
Input register	741	1	Alarmhandler_FireAlarm41_Status	Fire Alarm Damper/detector 41
Discrete input	742		Alarmhandler_FireAlarm42	Fire Alarm Damper/detector 42
Input register	742	1	Alarmhandler_FireAlarm42_Status	Fire Alarm Damper/detector 42
Discrete input	743		Alarmhandler_FireAlarm43	Fire Alarm Damper/detector 43
Input register	743	1	Alarmhandler_FireAlarm43_Status	Fire Alarm Damper/detector 43
Discrete input	744		Alarmhandler_FireAlarm44	Fire Alarm Damper/detector 44
Input register	744	1	Alarmhandler_FireAlarm44_Status	Fire Alarm Damper/detector 44
Discrete input	745		Alarmhandler_FireAlarm45	Fire Alarm Damper/detector 45
Input register	745	1	Alarmhandler_FireAlarm45_Status	Fire Alarm Damper/detector 45
Discrete input	746		Alarmhandler_FireAlarm46	Fire Alarm Damper/detector 46
Input register	746	1	Alarmhandler_FireAlarm46_Status	Fire Alarm Damper/detector 46
Discrete input	747		Alarmhandler_FireAlarm47	Fire Alarm Damper/detector 47
Input register	747	1	Alarmhandler_FireAlarm47_Status	Fire Alarm Damper/detector 47
Discrete input	748		Alarmhandler_FireAlarm48	Fire Alarm Damper/detector 48
Input register	748	1	Alarmhandler_FireAlarm48_Status	Fire Alarm Damper/detector 48
Discrete input	749		Alarmhandler_FireAlarm49	Fire Alarm Damper/detector 49
Input register	749	1	Alarmhandler_FireAlarm49_Status	Fire Alarm Damper/detector 49
Discrete input	705		Alarmhandler_FireAlarm5	Fire Alarm Damper/detector 5
Input register	705	1	Alarmhandler_FireAlarm5_Status	Fire Alarm Damper/detector 5
Discrete input	750		Alarmhandler_FireAlarm50	Fire Alarm Damper/detector 50
Input register	750	1	Alarmhandler_FireAlarm50_Status	Fire Alarm Damper/detector 50
Discrete input	751		Alarmhandler_FireAlarm51	Fire Alarm Damper/detector 51
Input register	751	1	Alarmhandler_FireAlarm51_Status	Fire Alarm Damper/detector 51
Discrete input	752		Alarmhandler_FireAlarm52	Fire Alarm Damper/detector 52
Input register	752	1	Alarmhandler_FireAlarm52_Status	Fire Alarm Damper/detector 52
Discrete input	753		Alarmhandler_FireAlarm53	Fire Alarm Damper/detector 53
Input register	753	1	Alarmhandler_FireAlarm53_Status	Fire Alarm Damper/detector 53
Discrete input	754		Alarmhandler_FireAlarm54	Fire Alarm Damper/detector 54
Input register	754	1	Alarmhandler_FireAlarm54_Status	Fire Alarm Damper/detector 54
Discrete input	755		Alarmhandler_FireAlarm55	Fire Alarm Damper/detector 55
Input register	755	1	Alarmhandler_FireAlarm55_Status	Fire Alarm Damper/detector 55
Discrete input	756		Alarmhandler_FireAlarm56	Fire Alarm Damper/detector 56
Input register	756	1	Alarmhandler_FireAlarm56_Status	Fire Alarm Damper/detector 56
Discrete input	757		Alarmhandler_FireAlarm57	Fire Alarm Damper/detector 57
Input register	757	1	Alarmhandler_FireAlarm57_Status	Fire Alarm Damper/detector 57
Discrete input	758		Alarmhandler_FireAlarm58	Fire Alarm Damper/detector 58
Input register	758	1	Alarmhandler_FireAlarm58_Status	Fire Alarm Damper/detector 58
Discrete input	759		Alarmhandler_FireAlarm59	Fire Alarm Damper/detector 59
Input register	759	1	Alarmhandler_FireAlarm59_Status	Fire Alarm Damper/detector 59
Discrete input	706		Alarmhandler_FireAlarm6	Fire Alarm Damper/detector 6
Input register	706	1	Alarmhandler_FireAlarm6_Status	Fire Alarm Damper/detector 6

Discrete input	760		Alarmhandler_FireAlarm60	Fire Alarm Damper/detector 60
Input register	760	1	Alarmhandler_FireAlarm60_Status	Fire Alarm Damper/detector 60
Discrete input	707		Alarmhandler_FireAlarm7	Fire Alarm Damper/detector 7
Input register	707	1	Alarmhandler_FireAlarm7_Status	Fire Alarm Damper/detector 7
Discrete input	708		Alarmhandler_FireAlarm8	Fire Alarm Damper/detector 8
Input register	708	1	Alarmhandler_FireAlarm8_Status	Fire Alarm Damper/detector 8
Discrete input	709		Alarmhandler_FireAlarm9	Fire Alarm Damper/detector 9
Input register	709	1	Alarmhandler_FireAlarm9_Status	Fire Alarm Damper/detector 9
Discrete input	821		Alarmhandler_ServiceCommAlarm1	Comm. Error Slave Unit 1
Input register	821	1	Alarmhandler_ServiceCommAlarm1_Status	Comm. Error Slave Unit 1
Discrete input	830		Alarmhandler_ServiceCommAlarm10	Comm. Error Slave Unit 10
Input register	830	1	Alarmhandler_ServiceCommAlarm10_Status	Comm. Error Slave Unit 10
Discrete input	831		Alarmhandler_ServiceCommAlarm11	Comm. Error Slave Unit 11
Input register	831	1	Alarmhandler_ServiceCommAlarm11_Status	Comm. Error Slave Unit 11
Discrete input	832		Alarmhandler_ServiceCommAlarm12	Comm. Error Slave Unit 12
Input register	832	1	Alarmhandler_ServiceCommAlarm12_Status	Comm. Error Slave Unit 12
Discrete input	833		Alarmhandler_ServiceCommAlarm13	Comm. Error Slave Unit 13
Input register	833	1	Alarmhandler_ServiceCommAlarm13_Status	Comm. Error Slave Unit 13
Discrete input	834		Alarmhandler_ServiceCommAlarm14	Comm. Error Slave Unit 14
Input register	834	1	Alarmhandler_ServiceCommAlarm14_Status	Comm. Error Slave Unit 14
Discrete input	835		Alarmhandler_ServiceCommAlarm15	Comm. Error Slave Unit 15
Input register	835	1	Alarmhandler_ServiceCommAlarm15_Status	Comm. Error Slave Unit 15
Discrete input	836		Alarmhandler_ServiceCommAlarm16	Comm. Error Slave Unit 16
Input register	836	1	Alarmhandler_ServiceCommAlarm16_Status	Comm. Error Slave Unit 16
Discrete input	837		Alarmhandler_ServiceCommAlarm17	Comm. Error Slave Unit 17
Input register	837	1	Alarmhandler_ServiceCommAlarm17_Status	Comm. Error Slave Unit 17
Discrete input	838		Alarmhandler_ServiceCommAlarm18	Comm. Error Slave Unit 18
Input register	838	1	Alarmhandler_ServiceCommAlarm18_Status	Comm. Error Slave Unit 18
Discrete input	839		Alarmhandler_ServiceCommAlarm19	Comm. Error Slave Unit 19
Input register	839	1	Alarmhandler_ServiceCommAlarm19_Status	Comm. Error Slave Unit 19
Discrete input	822		Alarmhandler_ServiceCommAlarm2	Comm. Error Slave Unit 2
Input register	822	1	Alarmhandler_ServiceCommAlarm2_Status	Comm. Error Slave Unit 2
Discrete input	840		Alarmhandler_ServiceCommAlarm20	Comm. Error Slave Unit 20
Input register	840	1	Alarmhandler_ServiceCommAlarm20_Status	Comm. Error Slave Unit 20
Discrete input	841		Alarmhandler_ServiceCommAlarm21	Comm. Error Slave Unit 21
Input register	841	1	Alarmhandler_ServiceCommAlarm21_Status	Comm. Error Slave Unit 21
Discrete input	842		Alarmhandler_ServiceCommAlarm22	Comm. Error Slave Unit 22
Input register	842	1	Alarmhandler_ServiceCommAlarm22_Status	Comm. Error Slave Unit 22
Discrete input	843		Alarmhandler_ServiceCommAlarm23	Comm. Error Slave Unit 23
Input register	843	1	Alarmhandler_ServiceCommAlarm23_Status	Comm. Error Slave Unit 23
Discrete input	844		Alarmhandler_ServiceCommAlarm24	Comm. Error Slave Unit 24
Input register	844	1	Alarmhandler_ServiceCommAlarm24_Status	Comm. Error Slave Unit 24
Discrete input	845		Alarmhandler_ServiceCommAlarm25	Comm. Error Slave Unit 25
Input register	845	1	Alarmhandler_ServiceCommAlarm25_Status	Comm. Error Slave Unit 25
Discrete input	846		Alarmhandler_ServiceCommAlarm26	Comm. Error Slave Unit 26

Input register	846	1	Alarmhandler_ServiceCommAlarm26_Status	Comm. Error Slave Unit 26
Discrete input	847		Alarmhandler_ServiceCommAlarm27	Comm. Error Slave Unit 27
Input register	847	1	Alarmhandler_ServiceCommAlarm27_Status	Comm. Error Slave Unit 27
Discrete input	848		Alarmhandler_ServiceCommAlarm28	Comm. Error Slave Unit 28
Input register	848	1	Alarmhandler_ServiceCommAlarm28_Status	Comm. Error Slave Unit 28
Discrete input	849		Alarmhandler_ServiceCommAlarm29	Comm. Error Slave Unit 29
Input register	849	1	Alarmhandler_ServiceCommAlarm29_Status	Comm. Error Slave Unit 29
Discrete input	823		Alarmhandler_ServiceCommAlarm3	Comm. Error Slave Unit 3
Input register	823	1	Alarmhandler_ServiceCommAlarm3_Status	Comm. Error Slave Unit 3
Discrete input	850		Alarmhandler_ServiceCommAlarm30	Comm. Error Slave Unit 30
Input register	850	1	Alarmhandler_ServiceCommAlarm30_Status	Comm. Error Slave Unit 30
Discrete input	851		Alarmhandler_ServiceCommAlarm31	Comm. Error Slave Unit 31
Input register	851	1	Alarmhandler_ServiceCommAlarm31_Status	Comm. Error Slave Unit 31
Discrete input	852		Alarmhandler_ServiceCommAlarm32	Comm. Error Slave Unit 32
Input register	852	1	Alarmhandler_ServiceCommAlarm32_Status	Comm. Error Slave Unit 32
Discrete input	853		Alarmhandler_ServiceCommAlarm33	Comm. Error Slave Unit 33
Input register	853	1	Alarmhandler_ServiceCommAlarm33_Status	Comm. Error Slave Unit 33
Discrete input	854		Alarmhandler_ServiceCommAlarm34	Comm. Error Slave Unit 34
Input register	854	1	Alarmhandler_ServiceCommAlarm34_Status	Comm. Error Slave Unit 34
Discrete input	855		Alarmhandler_ServiceCommAlarm35	Comm. Error Slave Unit 35
Input register	855	1	Alarmhandler_ServiceCommAlarm35_Status	Comm. Error Slave Unit 35
Discrete input	856		Alarmhandler_ServiceCommAlarm36	Comm. Error Slave Unit 36
Input register	856	1	Alarmhandler_ServiceCommAlarm36_Status	Comm. Error Slave Unit 36
Discrete input	857		Alarmhandler_ServiceCommAlarm37	Comm. Error Slave Unit 37
Input register	857	1	Alarmhandler_ServiceCommAlarm37_Status	Comm. Error Slave Unit 37
Discrete input	858		Alarmhandler_ServiceCommAlarm38	Comm. Error Slave Unit 38
Input register	858	1	Alarmhandler_ServiceCommAlarm38_Status	Comm. Error Slave Unit 38
Discrete input	859		Alarmhandler_ServiceCommAlarm39	Comm. Error Slave Unit 39
Input register	859	1	Alarmhandler_ServiceCommAlarm39_Status	Comm. Error Slave Unit 39
Discrete input	824		Alarmhandler_ServiceCommAlarm4	Comm. Error Slave Unit 4
Input register	824	1	Alarmhandler_ServiceCommAlarm4_Status	Comm. Error Slave Unit 4
Discrete input	860		Alarmhandler_ServiceCommAlarm40	Comm. Error Slave Unit 40
Input register	860	1	Alarmhandler_ServiceCommAlarm40_Status	Comm. Error Slave Unit 40
Discrete input	861		Alarmhandler_ServiceCommAlarm41	Comm. Error Slave Unit 41
Input register	861	1	Alarmhandler_ServiceCommAlarm41_Status	Comm. Error Slave Unit 41
Discrete input	862		Alarmhandler_ServiceCommAlarm42	Comm. Error Slave Unit 42
Input register	862	1	Alarmhandler_ServiceCommAlarm42_Status	Comm. Error Slave Unit 42
Discrete input	863		Alarmhandler_ServiceCommAlarm43	Comm. Error Slave Unit 43
Input register	863	1	Alarmhandler_ServiceCommAlarm43_Status	Comm. Error Slave Unit 43
Discrete input	864		Alarmhandler_ServiceCommAlarm44	Comm. Error Slave Unit 44
Input register	864	1	Alarmhandler_ServiceCommAlarm44_Status	Comm. Error Slave Unit 44
Discrete input	865		Alarmhandler_ServiceCommAlarm45	Comm. Error Slave Unit 45
Input register	865	1	Alarmhandler_ServiceCommAlarm45_Status	Comm. Error Slave Unit 45
Discrete input	866		Alarmhandler_ServiceCommAlarm46	Comm. Error Slave Unit 46
Input register	866	1	Alarmhandler_ServiceCommAlarm46_Status	Comm. Error Slave Unit 46

Discrete input	867		Alarmhandler_ServiceCommAlarm47	Comm. Error Slave Unit 47
Input register	867	1	Alarmhandler_ServiceCommAlarm47_Status	Comm. Error Slave Unit 47
Discrete input	868		Alarmhandler_ServiceCommAlarm48	Comm. Error Slave Unit 48
Input register	868	1	Alarmhandler_ServiceCommAlarm48_Status	Comm. Error Slave Unit 48
Discrete input	869		Alarmhandler_ServiceCommAlarm49	Comm. Error Slave Unit 49
Input register	869	1	Alarmhandler_ServiceCommAlarm49_Status	Comm. Error Slave Unit 49
Discrete input	825		Alarmhandler_ServiceCommAlarm5	Comm. Error Slave Unit 5
Input register	825	1	Alarmhandler_ServiceCommAlarm5_Status	Comm. Error Slave Unit 5
Discrete input	870		Alarmhandler_ServiceCommAlarm50	Comm. Error Slave Unit 50
Input register	870	1	Alarmhandler_ServiceCommAlarm50_Status	Comm. Error Slave Unit 50
Discrete input	871		Alarmhandler_ServiceCommAlarm51	Comm. Error Slave Unit 51
Input register	871	1	Alarmhandler_ServiceCommAlarm51_Status	Comm. Error Slave Unit 51
Discrete input	872		Alarmhandler_ServiceCommAlarm52	Comm. Error Slave Unit 52
Input register	872	1	Alarmhandler_ServiceCommAlarm52_Status	Comm. Error Slave Unit 52
Discrete input	873		Alarmhandler_ServiceCommAlarm53	Comm. Error Slave Unit 53
Input register	873	1	Alarmhandler_ServiceCommAlarm53_Status	Comm. Error Slave Unit 53
Discrete input	874		Alarmhandler_ServiceCommAlarm54	Comm. Error Slave Unit 54
Input register	874	1	Alarmhandler_ServiceCommAlarm54_Status	Comm. Error Slave Unit 54
Discrete input	875		Alarmhandler_ServiceCommAlarm55	Comm. Error Slave Unit 55
Input register	875	1	Alarmhandler_ServiceCommAlarm55_Status	Comm. Error Slave Unit 55
Discrete input	876		Alarmhandler_ServiceCommAlarm56	Comm. Error Slave Unit 56
Input register	876	1	Alarmhandler_ServiceCommAlarm56_Status	Comm. Error Slave Unit 56
Discrete input	877		Alarmhandler_ServiceCommAlarm57	Comm. Error Slave Unit 57
Input register	877	1	Alarmhandler_ServiceCommAlarm57_Status	Comm. Error Slave Unit 57
Discrete input	878		Alarmhandler_ServiceCommAlarm58	Comm. Error Slave Unit 58
Input register	878	1	Alarmhandler_ServiceCommAlarm58_Status	Comm. Error Slave Unit 58
Discrete input	879		Alarmhandler_ServiceCommAlarm59	Comm. Error Slave Unit 59
Input register	879	1	Alarmhandler_ServiceCommAlarm59_Status	Comm. Error Slave Unit 59
Discrete input	826		Alarmhandler_ServiceCommAlarm6	Comm. Error Slave Unit 6
Input register	826	1	Alarmhandler_ServiceCommAlarm6_Status	Comm. Error Slave Unit 6
Discrete input	880		Alarmhandler_ServiceCommAlarm60	Comm. Error Slave Unit 60
Input register	880	1	Alarmhandler_ServiceCommAlarm60_Status	Comm. Error Slave Unit 60
Discrete input	827		Alarmhandler_ServiceCommAlarm7	Comm. Error Slave Unit 7
Input register	827	1	Alarmhandler_ServiceCommAlarm7_Status	Comm. Error Slave Unit 7
Discrete input	828		Alarmhandler_ServiceCommAlarm8	Comm. Error Slave Unit 8
Input register	828	1	Alarmhandler_ServiceCommAlarm8_Status	Comm. Error Slave Unit 8
Discrete input	829		Alarmhandler_ServiceCommAlarm9	Comm. Error Slave Unit 9
Input register	829	1	Alarmhandler_ServiceCommAlarm9_Status	Comm. Error Slave Unit 9
Discrete input	761		Alarmhandler_ServiceDamperAlarm1	Service Alarm Damper/detector 1
Input register	761	1	Alarmhandler_ServiceDamperAlarm1_Status	Service Alarm Damper/detector 1
Discrete input	770		Alarmhandler_ServiceDamperAlarm10	Service Alarm Damper/detector 10
Input register	770	1	Alarmhandler_ServiceDamperAlarm10_Status	Service Alarm Damper/detector 10
Discrete input	771		Alarmhandler_ServiceDamperAlarm11	Service Alarm Damper/detector 11
Input register	771	1	Alarmhandler_ServiceDamperAlarm11_Status	Service Alarm Damper/detector 11
Discrete input	772		Alarmhandler_ServiceDamperAlarm12	Service Alarm Damper/detector 12

Input register	772	1	Alarmhandler_ServiceDamperAlarm12_Status	Service Alarm Damper/detector 12
Discrete input	773		Alarmhandler_ServiceDamperAlarm13	Service Alarm Damper/detector 13
Input register	773	1	Alarmhandler_ServiceDamperAlarm13_Status	Service Alarm Damper/detector 13
Discrete input	774		Alarmhandler_ServiceDamperAlarm14	Service Alarm Damper/detector 14
Input register	774	1	Alarmhandler_ServiceDamperAlarm14_Status	Service Alarm Damper/detector 14
Discrete input	775		Alarmhandler_ServiceDamperAlarm15	Service Alarm Damper/detector 15
Input register	775	1	Alarmhandler_ServiceDamperAlarm15_Status	Service Alarm Damper/detector 15
Discrete input	776		Alarmhandler_ServiceDamperAlarm16	Service Alarm Damper/detector 16
Input register	776	1	Alarmhandler_ServiceDamperAlarm16_Status	Service Alarm Damper/detector 16
Discrete input	777		Alarmhandler_ServiceDamperAlarm17	Service Alarm Damper/detector 17
Input register	777	1	Alarmhandler_ServiceDamperAlarm17_Status	Service Alarm Damper/detector 17
Discrete input	778		Alarmhandler_ServiceDamperAlarm18	Service Alarm Damper/detector 18
Input register	778	1	Alarmhandler_ServiceDamperAlarm18_Status	Service Alarm Damper/detector 18
Discrete input	779		Alarmhandler_ServiceDamperAlarm19	Service Alarm Damper/detector 19
Input register	779	1	Alarmhandler_ServiceDamperAlarm19_Status	Service Alarm Damper/detector 19
Discrete input	762		Alarmhandler_ServiceDamperAlarm2	Service Alarm Damper/detector 2
Input register	762	1	Alarmhandler_ServiceDamperAlarm2_Status	Service Alarm Damper/detector 2
Discrete input	780		Alarmhandler_ServiceDamperAlarm20	Service Alarm Damper/detector 20
Input register	780	1	Alarmhandler_ServiceDamperAlarm20_Status	Service Alarm Damper/detector 20
Discrete input	781		Alarmhandler_ServiceDamperAlarm21	Service Alarm Damper/detector 21
Input register	781	1	Alarmhandler_ServiceDamperAlarm21_Status	Service Alarm Damper/detector 21
Discrete input	782		Alarmhandler_ServiceDamperAlarm22	Service Alarm Damper/detector 22
Input register	782	1	Alarmhandler_ServiceDamperAlarm22_Status	Service Alarm Damper/detector 22
Discrete input	783		Alarmhandler_ServiceDamperAlarm23	Service Alarm Damper/detector 23
Input register	783	1	Alarmhandler_ServiceDamperAlarm23_Status	Service Alarm Damper/detector 23
Discrete input	784		Alarmhandler_ServiceDamperAlarm24	Service Alarm Damper/detector 24
Input register	784	1	Alarmhandler_ServiceDamperAlarm24_Status	Service Alarm Damper/detector 24
Discrete input	785		Alarmhandler_ServiceDamperAlarm25	Service Alarm Damper/detector 25
Input register	785	1	Alarmhandler_ServiceDamperAlarm25_Status	Service Alarm Damper/detector 25
Discrete input	786		Alarmhandler_ServiceDamperAlarm26	Service Alarm Damper/detector 26
Input register	786	1	Alarmhandler_ServiceDamperAlarm26_Status	Service Alarm Damper/detector 26
Discrete input	787		Alarmhandler_ServiceDamperAlarm27	Service Alarm Damper/detector 27
Input register	787	1	Alarmhandler_ServiceDamperAlarm27_Status	Service Alarm Damper/detector 27
Discrete input	788		Alarmhandler_ServiceDamperAlarm28	Service Alarm Damper/detector 28
Input register	788	1	Alarmhandler_ServiceDamperAlarm28_Status	Service Alarm Damper/detector 28
Discrete input	789		Alarmhandler_ServiceDamperAlarm29	Service Alarm Damper/detector 29
Input register	789	1	Alarmhandler_ServiceDamperAlarm29_Status	Service Alarm Damper/detector 29
Discrete input	763		Alarmhandler_ServiceDamperAlarm3	Service Alarm Damper/detector 3
Input register	763	1	Alarmhandler_ServiceDamperAlarm3_Status	Service Alarm Damper/detector 3
Discrete input	790		Alarmhandler_ServiceDamperAlarm30	Service Alarm Damper/detector 30
Input register	790	1	Alarmhandler_ServiceDamperAlarm30_Status	Service Alarm Damper/detector 30
Discrete input	791		Alarmhandler_ServiceDamperAlarm31	Service Alarm Damper/detector 31
Input register	791	1	Alarmhandler_ServiceDamperAlarm31_Status	Service Alarm Damper/detector 31
Discrete input	792		Alarmhandler_ServiceDamperAlarm32	Service Alarm Damper/detector 32
Input register	792	1	Alarmhandler_ServiceDamperAlarm32_Status	Service Alarm Damper/detector 32

Discrete input	793		Alarmhandler_ServiceDamperAlarm33	Service Alarm Damper/detector 33
Input register	793	1	Alarmhandler_ServiceDamperAlarm33_Status	Service Alarm Damper/detector 33
Discrete input	794		Alarmhandler_ServiceDamperAlarm34	Service Alarm Damper/detector 34
Input register	794	1	Alarmhandler_ServiceDamperAlarm34_Status	Service Alarm Damper/detector 34
Discrete input	795		Alarmhandler_ServiceDamperAlarm35	Service Alarm Damper/detector 35
Input register	795	1	Alarmhandler_ServiceDamperAlarm35_Status	Service Alarm Damper/detector 35
Discrete input	796		Alarmhandler_ServiceDamperAlarm36	Service Alarm Damper/detector 36
Input register	796	1	Alarmhandler_ServiceDamperAlarm36_Status	Service Alarm Damper/detector 36
Discrete input	797		Alarmhandler_ServiceDamperAlarm37	Service Alarm Damper/detector 37
Input register	797	1	Alarmhandler_ServiceDamperAlarm37_Status	Service Alarm Damper/detector 37
Discrete input	798		Alarmhandler_ServiceDamperAlarm38	Service Alarm Damper/detector 38
Input register	798	1	Alarmhandler_ServiceDamperAlarm38_Status	Service Alarm Damper/detector 38
Discrete input	799		Alarmhandler_ServiceDamperAlarm39	Service Alarm Damper/detector 39
Input register	799	1	Alarmhandler_ServiceDamperAlarm39_Status	Service Alarm Damper/detector 39
Discrete input	764		Alarmhandler_ServiceDamperAlarm4	Service Alarm Damper/detector 4
Input register	764	1	Alarmhandler_ServiceDamperAlarm4_Status	Service Alarm Damper/detector 4
Discrete input	800		Alarmhandler_ServiceDamperAlarm40	Service Alarm Damper/detector 40
Input register	800	1	Alarmhandler_ServiceDamperAlarm40_Status	Service Alarm Damper/detector 40
Discrete input	801		Alarmhandler_ServiceDamperAlarm41	Service Alarm Damper/detector 41
Input register	801	1	Alarmhandler_ServiceDamperAlarm41_Status	Service Alarm Damper/detector 41
Discrete input	802		Alarmhandler_ServiceDamperAlarm42	Service Alarm Damper/detector 42
Input register	802	1	Alarmhandler_ServiceDamperAlarm42_Status	Service Alarm Damper/detector 42
Discrete input	803		Alarmhandler_ServiceDamperAlarm43	Service Alarm Damper/detector 43
Input register	803	1	Alarmhandler_ServiceDamperAlarm43_Status	Service Alarm Damper/detector 43
Discrete input	804		Alarmhandler_ServiceDamperAlarm44	Service Alarm Damper/detector 44
Input register	804	1	Alarmhandler_ServiceDamperAlarm44_Status	Service Alarm Damper/detector 44
Discrete input	805		Alarmhandler_ServiceDamperAlarm45	Service Alarm Damper/detector 45
Input register	805	1	Alarmhandler_ServiceDamperAlarm45_Status	Service Alarm Damper/detector 45
Discrete input	806		Alarmhandler_ServiceDamperAlarm46	Service Alarm Damper/detector 46
Input register	806	1	Alarmhandler_ServiceDamperAlarm46_Status	Service Alarm Damper/detector 46
Discrete input	807		Alarmhandler_ServiceDamperAlarm47	Service Alarm Damper/detector 47
Input register	807	1	Alarmhandler_ServiceDamperAlarm47_Status	Service Alarm Damper/detector 47
Discrete input	808		Alarmhandler_ServiceDamperAlarm48	Service Alarm Damper/detector 48
Input register	808	1	Alarmhandler_ServiceDamperAlarm48_Status	Service Alarm Damper/detector 48
Discrete input	809		Alarmhandler_ServiceDamperAlarm49	Service Alarm Damper/detector 49
Input register	809	1	Alarmhandler_ServiceDamperAlarm49_Status	Service Alarm Damper/detector 49
Discrete input	765		Alarmhandler_ServiceDamperAlarm5	Service Alarm Damper/detector 5
Input register	765	1	Alarmhandler_ServiceDamperAlarm5_Status	Service Alarm Damper/detector 5
Discrete input	810		Alarmhandler_ServiceDamperAlarm50	Service Alarm Damper/detector 50
Input register	810	1	Alarmhandler_ServiceDamperAlarm50_Status	Service Alarm Damper/detector 50
Discrete input	811		Alarmhandler_ServiceDamperAlarm51	Service Alarm Damper/detector 51
Input register	811	1	Alarmhandler_ServiceDamperAlarm51_Status	Service Alarm Damper/detector 51
Discrete input	812		Alarmhandler_ServiceDamperAlarm52	Service Alarm Damper/detector 52
Input register	812	1	Alarmhandler_ServiceDamperAlarm52_Status	Service Alarm Damper/detector 52
Discrete input	813		Alarmhandler_ServiceDamperAlarm53	Service Alarm Damper/detector 53

Input register	813	1	Alarmhandler_ServiceDamperAlarm53_Status	Service Alarm Damper/detector 53
Discrete input	814		Alarmhandler_ServiceDamperAlarm54	Service Alarm Damper/detector 54
Input register	814	1	Alarmhandler_ServiceDamperAlarm54_Status	Service Alarm Damper/detector 54
Discrete input	815		Alarmhandler_ServiceDamperAlarm55	Service Alarm Damper/detector 55
Input register	815	1	Alarmhandler_ServiceDamperAlarm55_Status	Service Alarm Damper/detector 55
Discrete input	816		Alarmhandler_ServiceDamperAlarm56	Service Alarm Damper/detector 56
Input register	816	1	Alarmhandler_ServiceDamperAlarm56_Status	Service Alarm Damper/detector 56
Discrete input	817		Alarmhandler_ServiceDamperAlarm57	Service Alarm Damper/detector 57
Input register	817	1	Alarmhandler_ServiceDamperAlarm57_Status	Service Alarm Damper/detector 57
Discrete input	818		Alarmhandler_ServiceDamperAlarm58	Service Alarm Damper/detector 58
Input register	818	1	Alarmhandler_ServiceDamperAlarm58_Status	Service Alarm Damper/detector 58
Discrete input	819		Alarmhandler_ServiceDamperAlarm59	Service Alarm Damper/detector 59
Input register	819	1	Alarmhandler_ServiceDamperAlarm59_Status	Service Alarm Damper/detector 59
Discrete input	766		Alarmhandler_ServiceDamperAlarm6	Service Alarm Damper/detector 6
Input register	766	1	Alarmhandler_ServiceDamperAlarm6_Status	Service Alarm Damper/detector 6
Discrete input	820		Alarmhandler_ServiceDamperAlarm60	Service Alarm Damper/detector 60
Input register	820	1	Alarmhandler_ServiceDamperAlarm60_Status	Service Alarm Damper/detector 60
Discrete input	767		Alarmhandler_ServiceDamperAlarm7	Service Alarm Damper/detector 7
Input register	767	1	Alarmhandler_ServiceDamperAlarm7_Status	Service Alarm Damper/detector 7
Discrete input	768		Alarmhandler_ServiceDamperAlarm8	Service Alarm Damper/detector 8
Input register	768	1	Alarmhandler_ServiceDamperAlarm8_Status	Service Alarm Damper/detector 8
Discrete input	769		Alarmhandler_ServiceDamperAlarm9	Service Alarm Damper/detector 9
Input register	769	1	Alarmhandler_ServiceDamperAlarm9_Status	Service Alarm Damper/detector 9
Holding register	700	1	AlarmS.AlaAcknow	External alarm acknowledge by setting this signal to the alarm number that should be acknowledge.
Holding register	701	1	AlarmS.AlaBlock	External alarm blocking by setting this signal to the alarm number that should be blocked.
Holding register	702	1	AlarmS.AlaUnblock	External alarm unblocking by setting this signal to the alarm number that should be unblocked.
Discrete input	883		CommandHandler_DamperManual	Dampers in Manual Mode
Input register	883	1	CommandHandler_DamperManual_Status	Dampers in Manual Mode
Discrete input	882		CommandHandler_TestWarning	Damper Test Due in 1 Week
Input register	882	1	CommandHandler_TestWarning_Status	Damper Test Due in 1 Week
Input register	40	1	ControllerBuilder.Dampers_Command	Executed command: 0=None 1=Enter Address Mode 2=Leave Address Mode 3=Close Dampers 4=Open Dampers 5=Test Procedure 6=Reset Detectors 7=Reset Watch Dog
Input register	51	1	ControllerBuilder.TestTimer_HoursLeft	Interval time due in (hours)
Input register	50	1	ControllerBuilder.TestTimer_MinutesLeft	Interval time due in (minutes)
Input register	792	1	Alarmhandler_ServiceDamperAlarm32_Status	Service Alarm Damper/detector 32

Input register	100	1	DamperPosition(1)	Position Damper 1: 0=NA 1=In between 2=Closed 3=Open 4=Error
Input register	118	1	DamperPosition(10)	Position Damper 10:
Input register	120	1	DamperPosition(11)	Position Damper 11:
Input register	122	1	DamperPosition(12)	Position Damper 12:
Input register	124	1	DamperPosition(13)	Position Damper 13:
Input register	126	1	DamperPosition(14)	Position Damper 14:
Input register	128	1	DamperPosition(15)	Position Damper 15:
Input register	130	1	DamperPosition(16)	Position Damper 16:
Input register	132	1	DamperPosition(17)	Position Damper 17:
Input register	134	1	DamperPosition(18)	Position Damper 18:
Input register	136	1	DamperPosition(19)	Position Damper 19:
Input register	102	1	DamperPosition(2)	Position Damper 2:
Input register	138	1	DamperPosition(20)	Position Damper 20:
Input register	140	1	DamperPosition(21)	Position Damper 21:
Input register	142	1	DamperPosition(22)	Position Damper 22:
Input register	144	1	DamperPosition(23)	Position Damper 23:
Input register	146	1	DamperPosition(24)	Position Damper 24:
Input register	148	1	DamperPosition(25)	Position Damper 25:
Input register	150	1	DamperPosition(26)	Position Damper 26:
Input register	152	1	DamperPosition(27)	Position Damper 27:
Input register	154	1	DamperPosition(28)	Position Damper 28:
Input register	156	1	DamperPosition(29)	Position Damper 29:
Input register	104	1	DamperPosition(3)	Position Damper 3:
Input register	158	1	DamperPosition(30)	Position Damper 30:
Input register	160	1	DamperPosition(31)	Position Damper 31:
Input register	162	1	DamperPosition(32)	Position Damper 32:
Input register	164	1	DamperPosition(33)	Position Damper 33:
Input register	166	1	DamperPosition(34)	Position Damper 34:
Input register	168	1	DamperPosition(35)	Position Damper 35:
Input register	170	1	DamperPosition(36)	Position Damper 36:
Input register	172	1	DamperPosition(37)	Position Damper 37:
Input register	174	1	DamperPosition(38)	Position Damper 38:
Input register	176	1	DamperPosition(39)	Position Damper 39:
Input register	106	1	DamperPosition(4)	Position Damper 4:
Input register	178	1	DamperPosition(40)	Position Damper 40:
Input register	180	1	DamperPosition(41)	Position Damper 41:
Input register	182	1	DamperPosition(42)	Position Damper 42:
Input register	184	1	DamperPosition(43)	Position Damper 43:
Input register	186	1	DamperPosition(44)	Position Damper 44:
Input register	188	1	DamperPosition(45)	Position Damper 45:

Input register	190	1	DamperPosition(46)	Position Damper 46:
Input register	192	1	DamperPosition(47)	Position Damper 47:
Input register	194	1	DamperPosition(48)	Position Damper 48:
Input register	196	1	DamperPosition(49)	Position Damper 49:
Input register	108	1	DamperPosition(5)	Position Damper 5:
Input register	198	1	DamperPosition(50)	Position Damper 50:
Input register	200	1	DamperPosition(51)	Position Damper 51:
Input register	202	1	DamperPosition(52)	Position Damper 52:
Input register	204	1	DamperPosition(53)	Position Damper 53:
Input register	206	1	DamperPosition(54)	Position Damper 54:
Input register	208	1	DamperPosition(55)	Position Damper 55:
Input register	210	1	DamperPosition(56)	Position Damper 56:
Input register	212	1	DamperPosition(57)	Position Damper 57:
Input register	214	1	DamperPosition(58)	Position Damper 58:
Input register	216	1	DamperPosition(59)	Position Damper 59:
Input register	110	1	DamperPosition(6)	Position Damper 6:
Input register	218	1	DamperPosition(60)	Position Damper 60:
Input register	112	1	DamperPosition(7)	Position Damper 7:
Input register	114	1	DamperPosition(8)	Position Damper 8:
Input register	116	1	DamperPosition(9)	Position Damper 9:
Input register	41	1	DelayTimeLeft	Time left to start in seconds
Input register	101	1	DetectorStatus(1)	Detector Status Damper 1: 0=Detector signal OK 1=Detector probably dirty 2=Too high or too low signal. Detector fault 3=Smoke indication 4=Not used 5=No answer
Input register	119	1	DetectorStatus(10)	Detector Status Damper 10:
Input register	121	1	DetectorStatus(11)	Detector Status Damper 11:
Input register	123	1	DetectorStatus(12)	Detector Status Damper 12:
Input register	125	1	DetectorStatus(13)	Detector Status Damper 13:
Input register	127	1	DetectorStatus(14)	Detector Status Damper 14:
Input register	129	1	DetectorStatus(15)	Detector Status Damper 15:
Input register	131	1	DetectorStatus(16)	Detector Status Damper 16:
Input register	133	1	DetectorStatus(17)	Detector Status Damper 17:
Input register	135	1	DetectorStatus(18)	Detector Status Damper 18:
Input register	137	1	DetectorStatus(19)	Detector Status Damper 19:
Input register	219	1	DetectorStatus(2)	Detector Status Damper 2:
Input register	103	1	DetectorStatus(2)	Detector Status Damper 2:
Input register	139	1	DetectorStatus(20)	Detector Status Damper 20:
Input register	141	1	DetectorStatus(21)	Detector Status Damper 21:
Input register	143	1	DetectorStatus(22)	Detector Status Damper 22:
Input register	145	1	DetectorStatus(23)	Detector Status Damper 23:
Input register	147	1	DetectorStatus(24)	Detector Status Damper 24:

Input register	149	1	DetectorStatus(25)	Detector Status Damper 25:
Input register	151	1	DetectorStatus(26)	Detector Status Damper 26:
Input register	153	1	DetectorStatus(27)	Detector Status Damper 27:
Input register	155	1	DetectorStatus(28)	Detector Status Damper 28:
Input register	157	1	DetectorStatus(29)	Detector Status Damper 29:
Input register	105	1	DetectorStatus(3)	Detector Status Damper 3:
Input register	159	1	DetectorStatus(30)	Detector Status Damper 30:
Input register	161	1	DetectorStatus(31)	Detector Status Damper 31:
Input register	163	1	DetectorStatus(32)	Detector Status Damper 32:
Input register	165	1	DetectorStatus(33)	Detector Status Damper 33:
Input register	167	1	DetectorStatus(34)	Detector Status Damper 34:
Input register	169	1	DetectorStatus(35)	Detector Status Damper 35:
Input register	171	1	DetectorStatus(36)	Detector Status Damper 36:
Input register	173	1	DetectorStatus(37)	Detector Status Damper 37:
Input register	175	1	DetectorStatus(38)	Detector Status Damper 38:
Input register	177	1	DetectorStatus(39)	Detector Status Damper 39:
Input register	107	1	DetectorStatus(4)	Detector Status Damper 4:
Input register	179	1	DetectorStatus(40)	Detector Status Damper 40:
Input register	181	1	DetectorStatus(41)	Detector Status Damper 41:
Input register	183	1	DetectorStatus(42)	Detector Status Damper 42:
Input register	185	1	DetectorStatus(43)	Detector Status Damper 43:
Input register	187	1	DetectorStatus(44)	Detector Status Damper 44:
Input register	189	1	DetectorStatus(45)	Detector Status Damper 45:
Input register	191	1	DetectorStatus(46)	Detector Status Damper 46:
Input register	193	1	DetectorStatus(47)	Detector Status Damper 47:
Input register	195	1	DetectorStatus(48)	Detector Status Damper 48:
Input register	197	1	DetectorStatus(49)	Detector Status Damper 49:
Input register	109	1	DetectorStatus(5)	Detector Status Damper 5:
Input register	199	1	DetectorStatus(50)	Detector Status Damper 50:
Input register	201	1	DetectorStatus(51)	Detector Status Damper 51:
Input register	203	1	DetectorStatus(52)	Detector Status Damper 52:
Input register	205	1	DetectorStatus(53)	Detector Status Damper 53:
Input register	207	1	DetectorStatus(54)	Detector Status Damper 54:
Input register	209	1	DetectorStatus(55)	Detector Status Damper 55:
Input register	211	1	DetectorStatus(56)	Detector Status Damper 56:
Input register	213	1	DetectorStatus(57)	Detector Status Damper 57:
Input register	215	1	DetectorStatus(58)	Detector Status Damper 58:
Input register	217	1	DetectorStatus(59)	Detector Status Damper 59:
Input register	111	1	DetectorStatus(6)	Detector Status Damper 6:
Input register	113	1	DetectorStatus(7)	Detector Status Damper 7:
Input register	115	1	DetectorStatus(8)	Detector Status Damper 8:
Input register	117	1	DetectorStatus(9)	Detector Status Damper 9:
Input register	30	10	DuctPressure	Actual duct pressure (Pa)
Holding register	32	1	FanSpeedMan	Manual Fan Speed in %
Holding register	31	1	FanSpeedManAutoSelect	Fan mode: 0=Manual off, 1=Manual on, 2=Auto

Discrete input	0		FireSection(1)	Fire in section 1
Discrete input	9		FireSection(10)	Fire in section 10
Discrete input	1		FireSection(2)	Fire in section 2
Discrete input	2		FireSection(3)	Fire in section 3
Discrete input	3		FireSection(4)	Fire in section 4
Discrete input	4		FireSection(5)	Fire in section 5
Discrete input	5		FireSection(6)	Fire in section 6
Discrete input	6		FireSection(7)	Fire in section 7
Discrete input	7		FireSection(8)	Fire in section 8
Discrete input	8		FireSection(9)	Fire in section 9
Input register	0	1	MasterMode	Master status: 0=Addressing 1=Manual Close 2=A Alarm 3=Test Procedure 4=Detector Reset 5=Normal Operation 6=Idle 7=Manual Open
Holding register	54	1	Parameters.Test1StartDay	Weekly timer: 0=Not used, 1=Monday, 2=Tuesday, 3=Wednesday, 4=Thursday, 5=Friday, 6=Saturday, 7=Sunday
Holding register	53	1	Parameters.Test1WeekInterval	Weekly timer: weeks
Holding register	50	1	Parameters.TestTimerInterval	Timer interval in hours
Holding register	30	10	PressureSetP	Duct pressure setpoint (Pa)
Holding register	203	1	QSystem.Date	Real time clock: Day of month (1-31)
Holding register	201	1	QSystem.Hour	Real time clock: Hour (0-23)
Holding register	200	1	QSystem.Minute	Real time clock: Minute (0-59)
Holding register	204	1	QSystem.Month	Real time clock: Month (1-12)
Holding register	202	1	QSystem.WDay	Real time clock: Day of Week (1-7, 1=Monday)
Holding register	205	1	QSystem.Year	Real time clock: Year (0-99)
Discrete input	881		SEF_Alarm	SEF Alarm
Input register	881	1	SEF_Alarm_Status	SEF Alarm
Holding register	55	1	StartTest1_MinuteStart	Weekly timer starts at (minute)
Coil	51		Test1StartEnable	Weekly timer: 0=Disabled, 1=Enabled
Coil	40		TestAlarm_Alarm	Test A Alarm: 0=No, 1=Yes
Holding register	40	1	TestDelayTime	Test delay time in minutes
Coil	41		TestTimer_ManualStart	Test all dampers: 0=No, 1=Yes
Coil	42		TestTimer_ManualStartAllConfirmed	Confirm test all dampers: 0=No, 1=Yes
Coil	43		TestTimer_ManualStartIndConfirmed	Confirm test individual damper: 0=No, 1=Yes
Holding register	41	1	TestTimer_SlaveUnitTemp	Test individual damper (1-60)
Coil	50		TestTimerEnabled	Timer: 0=Disabled, 1=Enabled
Holding register	52	1	TestTimerHourSync	Chosen interval time (hours)
Holding register	51	1	TestTimerMinuteSync	Chosen interval time (minutes)
Input register	186	1	DamperPosition(44)	Position Damper 44:
Input register	188	1	DamperPosition(45)	Position Damper 45:



Good Thinking

At Lindab, good thinking is a philosophy that guides us in everything we do. We have made it our mission to create a healthy indoor climate – and to simplify the construction of sustainable buildings. We do that by designing innovative products and solutions that are easy to use, as well as offering efficient availability and logistics. We are also working on ways to reduce our impact on our environment and climate. We do that by developing methods to produce our solutions using a minimum of energy and natural resources, and by reducing negative effects on the environment. We use steel in our products. It's one of few materials that can be recycled an infinite number of times without losing any of its properties. That means less carbon emissions in nature and less energy wasted.

We simplify construction