

Lindab Atrium Plana

Radiant cooling- and heating panels Installation instructions



Atrium Plana

2. Control of delivery	3
2.1 Before starting	3
2.2 Safe operation	3
2.3 Receipt of goods	3
2.4 Unloading of goods	3
2.5 Handling / Carrying	3
2.6 Tools	4
2.7 Installation	4
2.8 Where to find additional instructions or technical documentation	4
2.9 Cleaning after assembly / before commissioning	ıg 4
2.10 Packing, unpacking guideline	5
2.11 Product labelling	6
2.12 Order code	6
2.13 Order code examples	6
2.14 Label	6
2.15 Contents of order	7
2.16 Plus features	7
2.17 Accessories	7
2.17.1 Threaded rod kit (Hangers)	7
2.17.2 Flexible hoses	7
2.17.3 Transformer	7
2.17.4 Tectite fittings	7
3. Product specification	
3.1 Dimensions	
3.1.1 Heating or cooling 2-pipe water connection	
3.1.2 Type HC-ocmbined heating and cooling (4-pi	
water connection	
3.2 General structure	
3.3 Material data	
3.4 Environmental Declarations	
3.6 Water quality	
	10
	10
3.7 Air quality	
3.7 Air quality	10
3.7 Air quality	10 11
3.7 Air quality	10 11 11
3.7 Air quality	10 11 11 11
3.7 Air quality	10 11 11 11
3.7 Air quality 3.8 Capacity test	10 11 11 11 12
3.7 Air quality 3.8 Capacity test	10 11 11 12 12 12
3.7 Air quality	10 11 11 12 12 12
3.7 Air quality	10 11 11 12 12 12
3.7 Air quality	10 11 11 12 12 12 13

5. Installation of product	14
5.1 Handling of product	14
5.2 Adaption to ceiling systems	14
5.2.1 Ceiling systems	14
5.3 General installation principles	15
5.4 Preparation for installation on the product	15
5.4.1 Mounting accessories Pendulum	15
5.4.2 Mounting accessories Pendulum + Suspension	1
hook	16
5.4.3 Mounting accessories - Wiring hanger system.	16
5.4.4 Mounting accessories - Threaded rod M6 +	
Suspension hook	17
5.4.5 Mounting in ceiling	17
5.4.6 Mounting direct to concrete	18
6. Adjustment and commissioning	19
6.1 Airflow and pressure	19
6.2 Adjustment of air distribution pattern	19
6.3 Measuring air pressure and	
calculating the air flow	19
6.4 Water flow rate	19
6.4.1 Pre-setting of valves	19
6.4.2 Balancing strategy	19
7. Maintenance	19
8. Accessories	19



Atrium Plana

1.2 Symbols



Heavy Load - 2 man job - It is recommended to use a "lift" for mounting.





2. Control of delivery

2.1 Before starting

Read through the entire installation instruction before commencing installation in order to determine which parts that needs to be performed and in what order to be done.

Lindab is a supplier of complete water products, but we offer also a wide range of accessories which suit perfectly to our water products simplifying your installation work, e.g. different type of hangers, push fittings, closing valves, thermostatic valves and actuators, flexible hoses, customized regulation components, customized cabeling and more. See also the separate document "Accessories."

Lindab will also provide you with a full ventilation system, with a wide range of Lindab Safe components. See also "Air Duct Systems."

2.2 Safe operation

Beware of sharp edges, especially of the coils (beams only). Always wear thin gloves and protective clothing.

All existing safety regulations must be observed when working with Lindab water products. Check the weights of the beams or the panels with the installation instruction before carrying.

2.3 Receipt of goods

Start by checking that the delivery is complete according to the order and that everything listed on the consignment note has been delivered. Then carry out a review of the products and make sure that nothing was damaged during transportation. If you discover damage that has occurred during delivery, it must be notified immediately.

Lindab is not responsible for costs associated with the replacement of products, that have been installed in any way other than shown in these installation instructions.

2.4 Unloading of goods

The beams and panels are normally delivered packed on wooden pallets. Lift the pallets carefully with a fork lift and place them on a dry and plain surface/ground. If the beams are delivered in single boxes, wooden blocks should be placed on the ground at one-metre intervals (or a pallet), before the boxes are been placed to store. Lindabs water

products must be stored on a plane surface in a dry and well ventilated place, preferably indoors. If they have to be stored outdoors, protect them with a waterproof cover and store them protected from rain beneath a roof or other until they are fitted.

2.5 Handling / Carrying

The beam or panel must be handled with care, ensuring that it will not be scratched or bended during transportation, preparation and installation.

Always carry the beams or panels piecewise into the building. Keep the product in the package as long as you can.

Never use piping connections or edges to lift them, neither when you unpack them nor when you carry them towards the construction site.



Do not place the product directly on the floor. Use the protective corners from package or other clean means from package to place the product before installation.

Be careful if you must carry a long panel horizontally; if the panels are bended lengthwise, the profiles may be deformed and the piping could loosen from the panel. When opening the box with a knife, be careful not to damage the product.

Each beam or panel is equipped with protective film to avoid any damage during transportation and handling on building site. The film needs to be removed before commissioning the products.






Atrium Plana

2.6 Tools

To install the beam, panel or facade unit, the following tools are required.



2.7 Installation

It is important to use the correct hangers and the recommended amount for all installation principles. Different possible installation principles are shown in the installation instruction and hangers from Lindab should be used to ensure, that they are intended for the purpose and are safe to use.

Lindab's water products can be ordered, to be adapted to a wide range of different ceiling systems, please check installation instruction to ensure best adaptation.

The Lindab water products should always be installed separately hanged up from the recessed ceiling. The weight of the product should not be covered by the ceiling system.

Use plastic folio or other to protect the product during on site construction continually to keep the products in best condition and avoid any scratches.

2.8 Where to find additional instructions or technical documentation

In the following chapters we will refer to additional technical documents or/and instructions by a certain keyword written as a link.

You can also find relevant related documents with our Lindab Quick selection tool:

- 1. Visit www.lindQST.com
- 2. Select "documentation"
- 3. Select product
- 4. Find relevant documents under "Related documents"

2.9 Cleaning after assembly / before commissioning

Please remember to remove plastic folio and other protection material before commissioning and clean the product before hand over.



Atrium Plana

2.10 Packing, unpacking guideline







Never use water pipe connections for lifting













Atrium Plana

2.11 Product labelling



2.12 Order code



2.13 Order code examples

2.14 Label

On the label you'll find:

Sales order: Order identification number
 Production order: Production order no.
 Goods mark: Marking noted on order
 Product ID: Product number

Sign: To be signed when checked and commissioned on site





Atrium Plana

2.15 Contents of order

Standard package/order contains:

- Beam/panel
- Plus features (pre-installed in factory)
- Accessories (separate in smaller box)

2.16 Plus features

2.17 Accessories

Here are some general accessories. For full range and order numbers, see separate <u>Accessories</u> document. Go to "8. Accessories" in this document to find accessories order numbers.

2.17.1 Threaded rod kit (Hangers)



M8 x4 per beam when $L_{nom} \le 2700$ mm **M8 x6** per beam when $L_{nom} > 2400$ mm

Go to 5.4 "Preparation for installation on the product" for more details. *Order no: See Accessories.*

2.17.2 Flexible hoses



Order no: See Accessories.

2.17.3 Transformer



Order no: See Transformers.

2.17.4 Tectite fittings








See Accessories.

Atrium Plana

3. Product specification

The Lindab Atrium Plana is a simple yet powerfull radiant panel, with an uncomlicated design that ensures that the Atrium Plana does not draw attention on the building and interior design. The water pipes are made of copper. Nevertheless, water should be oxygen-free to prevent corrosion. It is made out of a thin aluminium plate with laser welded copper pipes on top. Atrium Plana is available as standard, in fine textured powder coating in signal white RAL 9003 or in pure white RAL 9010, gloss value 5 ± 1 . Other RAL colours on request. H- and HC panels are insulated with white extruded polystyrene foam and should not be placed in direct sunshine or underneath other heating- or ignition sources. Sparks and smoke must be avoided. (manufactured without the addition of CFC or HCFC gas i. e. freons). When heating is of minor importance.




		,								
Туре	В	Dry	Water	L _{nom}						
1,00	Width	weight	content	600	1200	1800	2400	3000	3600	
	[mm]	[kg /m]	[I/m]	A [mm]						
C-40 / H-40	392	2.1	0.4022		1188	1788	2388	2988	3588	
C-60 / H-60	592	3.0	0.8044	500						
C-90 / H-90	892	5.4	1.2066	588						
C-120 / H-120	1192	7.5	1.6088							
		x [mm]		119	269	419	204	204	204	
	Expansion at *HW: + 55/45°C			0.7 mm/m						
	Expansion at *HW: + 80/60°C			1.2 mm/m						
	Copper pipes quality			EN 12735-2 CU-DHP						
	Pi	ressure cla	SS	PN10						

Type C-/H- cooling or heating panel, specific measures and other data - *HW: Hot Water Tolerances for deflection: 2 mm deflection per 1 m off panel length/width.



Dimensions

Atrium Plana




Туре	В	Dry	Water	y ₁ y ₂		L _{nom}					
1,00	Width	weight	content	J 1	J 2	600	1200	1800	2400	3000	3600
	[mm]	[kg /m]	[I/m]	[m	m]	A [mm]					
HC-40	392	2.2	0.844	74	81	588	1188	1788	2388	2988	
HC-60	592	3.2	1.6088	37	68						0500
HC-90	892	5.5	2.011	74	83						3588
HC-120	1192	7.6	2.4132	74	95						
	X					119	269	419	204	204	204
	Expansion at *HW: + 55/45°C					0.7 mm/m					
	Expansion at *HW: + 80/60°C					1.2 mm/m					
		Copper pi	pes quality	/		EN 12735-2 CU-DHP					
	Pressure class					PN10					

Type HC- combined heating and cooling panel, specific measures and other data - *HW: Hot Water. Tolerances for deflection: 2 mm deflection per 1 m off panel length/width.



Atrium Plana

3.2 General structure



Atrium Plana panel - Copper pipe [1] laser welded [2] on aluminium front plate [3]

3.3 Material data

Туре	Plana Matrix			
Copper pipes, quality	EN-12735-2 CU-DHP			
Pressure class	PN10			

3.4 Environmental Declarations

Please follow the links below:

- Building product declaration
- Declaration of conformity

3.5 Pressure Class

The waterborne products in Lindab, active chilled beams (battery products), passive chilled beams (battery and strips products), facade units (battery) and radiant panels (strips and panels) are produced according to pressure class PN 10 according to EN 1333: 2006.

This means the maximal working pressure for the products at a water temperature of 20°C must not exceed 10 bar.

3.6 Water quality

Lindab recommend water treatment and quality to be according to VDI 2035-2.

- The water preparation and maintenance for the chilled beam water circuit must be handled by a specialist.
- To prevent corrosion, the water circuit must be airtight.
- The water system must also be equipped with aerators to remove any build-up air in the system.
- The water must be oxygen free, to prevent corrosion.
- The water system must be filled with potable water that complies with the "EC directive 98/83/EC."
- The pH value of water must be between approximately 6-9 pH.
- The water velocities should not exceed 1 m/s, and should be kept as close to the nominal flow as possible to minimize noise and optimise the energy yield.
- Use in-line strainers to remove dirt particles from the water.
- If the water contains any additive inhibitor, then it must be appropriate to use with copper and solder.

3.7 Air quality

3.8 Capacity test

Atrium Plana panels are tested according to EN-14240: 2003, EN-14037-2: 2016 and EN-14037-5: 2016 at accredited to EN ISO/ IEC 17025 notified body by DIBt according to (EU) No. 305/2011 NB 1428, WSPlab, Stuttgart, Germany and are CE-marked.



Atrium Plana

4. Connections

4.1. Water connections

If the control valves have been ordered separately, a special direction of the flow must be upheld to ensure correct flow through the control valve. Please note the flow direction indicator on the valve to insure correct installation in relation to the desired flow.

When connecting a panel or a beam with the piping system either a push-on fitting or a compression coupling should be used. Lindab have tested and recommends John Guest push on fittings as well as push-on fittings from Tectite (available as accessory. See <u>Accessories</u>).

To avoid sound being transported over the beam, we recommend to use our flexible hoses between the piping and the beam connections. See Accessories.

NB! Every control valve can create sound when it is installed directly connected to the water in- or outlet (or into the piping in close distance to the in- or outlet of the water product). To avoid unwanted sound generation we recommend to always use a Lindab control valve <u>LinFlow-A</u> (angled) or <u>LinFlow-S</u> (straight) and calculate the beam with the valve in <u>LindQST\waterborne</u> calculator.


4.1.1 Before installation


- Notice! The connection pipes are internally soft-welded, therefore it is not allowed to solder the beam to the pipes. For
 other than Lindab fittings and valves, please consult the installation guide for the specific fitting for further details on proper
 installation.
- Both inlet- and return pipes are covered by a plastic or rubber protection cover, which must be removed before installation.






- After removing the protection cover, make sure that the pipe is intact and undamaged, especially at the pipe end, as even small dents and scratches potentially pose a risk of leakage in the system.
- Eventually deburr the pipe ends on the inside and the outside, using a deburring tool before installation.








• Always remember to do a pressure test after assembly of the pipe work.



Atrium Plana

4.1.2 Push-on valve

- Mount a push-on valve to the pipe. Make sure the valve has the correct flow direction (see indication arrow on the valve) and
 that you have the correct valve, when integrated valve has been chosen (see indication on valve or follow cabelling to Regula
 Connect card). Cooper inserts aren't required!
- · Please refer to the suppliers manual.







4.1.3 Compression fitting

- While mounting a compression fitting, the pipe will be exposed to a big amount of force, creating a risk of crushing the pipe. To ensure that the pipe won't be crushed when mounting the compression fitting, a copper insert must be inserted into the pipe (always part of the delivery).
- The copper insert should be placed inside the pipe on the beam. Always support the copper pipe coil when inserting the copper insert into position.
- Mount a compression coupling and/or a valve to the pipe. Don't stress the nut too much, since this may crush the pipe.
- Please refer to the suppliers manual.

4.1.4 Flexible hoses

- Our flexible hoses with straight ends can be used with both push-on and compression fitting.
- We recommend to use our flexible hoses with push-on fittings, for easier and faster mounting.
- For the connection to an enclosed valve with integrated push on coupling a flexible hose with straight end (male) or with push on (female) and a short copper pipe can be used.
- Please refer to the suppliers manual.





* L_{min} = 70 mm (to ensure you can open the couplings again).

Lindab flexible hoses are available with straight end (male) for direct connection to Lindab valves also.




Atrium Plana

4.1.5 Possible connections water cooling or heating (2-pipe, standard)

All the Atrium Plana radiant panels can have either a "2-pipe water connection" or a "4-pipe water connection" as standard (see 4.1.6). The 2-pipe water connection beam contains one water circuit only (cooling or heating).

All water pipe connections are $\emptyset = 10$ mm.

Connect water with push-on or compression couplings or similar. Use the support sleeves. Do not solder! (see chapter 4.)



Atrium Plana

5. Installation of product


5.1 Handling of product

For the handling of the product please refer to 2.5.

5.2 Adaption to ceiling systems

5.2.1 Ceiling systems

Atrium Plana is ready for ceiling sytem 1 only, for others please contact local Lindab contact for further explanation/support.







Atrium Plana


5.3 General installation principles

Atrium Plana is installed either exposed or recessed in a suspended ceiling.

Installation types








5.4 Preparation for installation on the product

5.4.1 Mounting accessories - Pendulum



Pendulum:

1 pc, 180-300 mm (order no. 642480) 1 pc, 540-1000 mm (order no. 646742) 1 pc, 1750-2000 mm (order no. 653454)


1 pc, 1730-2000 mm (order no. 65545

1. 4 pcs for L < 2.4 m


2. 6 pcs for L \geq 2.4 m

Atrium Plana


5.4.2 Mounting accessories - Pendulum + Suspension hook




5.4.3 Mounting accessories - Wiring hanger system








5.4.5 Mounting in ceiling



Atrium Plana





Atrium Plana

6. Adjustment and commissioning

- 6.1 Airflow and pressure
- 6.2 Adjustment of air distribution pattern
- 6.3 Measuring air pressure and calculating the air flow

6.4 Water flow rate

6.4.1 Pre-setting of valves

All the control valves are delivered not set. The presetting has to be done on site. For the presetting of valves, please see <u>LinFlow-A</u> (Angled) and <u>LinFlow-S</u> (Straight) water valves documentation.

6.4.2 Balancing strategy

Lindab recommends always balancing the water system to guarantee thermal comfort in all areas, to avoid noise nuisance problems and to safe energy. A hydraulic balance is obvious to ensure that all the beams (panels or facade units) in the system will always be supplied with their required (planned) water flow rates.

Lindab refers to the proportional method, where all beams (panels or facade units) are balanced to the same proportion of the requested water flow rate.


7. Maintenance

The interval of cleaning depends on the indoor environment where the panel is placed.

Under optimal conditions the panels only need cleaning every 5 years.

Cleaning instructions

- Only use lukewarm water and a mild detergent.
- · When cleaning from above, the ceiling plate next to the panel must be removed
- then it will be possible to clean the panel from above



Check also Lindab's <u>Accessories</u> document.







Most of us spend the majority of our time indoors. Indoor climate is crucial to how we feel, how productive we are and if we stay healthy.

We at Lindab have therefore made it our most important objective to contribute to an indoor climate that improves people's lives. We do this by developing energy-efficient ventilation solutions and durable building products. We also aim to contribute to a better climate for our planet by working in a way that is sustainable for both people and the environment.

Lindab | For a better climate

