



TRC200

Mounting instruction

TRC200


Mount the shears on SR cutter bench




1. Remove pin CSSA2.



2. Mount adapter CSAD.



3. Secure CSAD with the locking bolt.



4. Mount shear TRC200 onto the adapter.

TRC200



5. Secure the shear by tightening the knob.



6. TRC 200 is ready to use.



Most of us spend the majority of our time indoors. Indoor climate is crucial to how we feel, how productive we are and if we stay healthy.

We at Lindab have therefore made it our most important objective to contribute to an indoor climate that improves people's lives. We do this by developing energy-efficient ventilation solutions and durable building products. We also aim to contribute to a better climate for our planet by working in a way that is sustainable for both people and the environment.

[Lindab | For a better climate](#)