

TGR-LHR




Description


Roof adapter, upper connection.
Use for connecting roof hood LHR to roof transition TGR.

For more information see [LHR](#).

Dimensions



















TGR



Ordering example

	TGR-LHR	5	400	400	1
Product					
Size					
A mm					
B mm					
Material					
Galvanized steel		1			
Stainl. acid-res. steel 1.4404		3			
Stainless steel 1.4301		4			
Zinc-magnesium ZM310		5			

Roof hood	H 	HV 	HU 	HN 	HF 	VHL 	LHR 	HRR 	HVR 		
	Hoods with circular connection						Hoods with rectangular connection				
Hood to adapter	Screw or bolt						Guiding profile	The hood is attached directly to the roof transition. – No adapter is needed.			
Adapter	TGR-OA Ø80–315 				Ø400–1250 		TGR-VHL Ø100–315 			Ø400–500 	
Adapter to roof transition	Screw										
Roof transition	TGR 										
Roof transition to connector	Guiding profile										
Connector	TGR-NA 					The roof transition is attached directly to the duct. – No connector is needed.					
Connector to duct	Screw, blind rivet or Lindab Click										
Duct	SR 					LKR 